

Lamp installation manual

Please keep for reference

Respect of customer,thank you for your purchase this produr,please read the instructions carefully before using.



- 1.Please in strict accordance with the instructions for installation
- 2.Please do not optional exchange lamps parts

Note:

- 1.Must cut off the power supply first,ensure the safety, according to the company to provide installation method in the operations.
- 2.Do not install in high temperature or moisture place,use power do not exceed the specified range(rated voltage AC110 v 50HZ/60HZ),lest cause damage to the lamps.
- 3.Install lamp body,please wear gloves.Avoid injuries and damage the light body surface.
- 4.To ensure safety,maintenance and check lamps,please entrust electical professionals responsible for construction work.
- 5.Please do not touch the random use of lamps and lanterns,happen abnormal phenomena,please quickly cut off the power supply,and with vendors contact.

Installation Instructions:

1.Bolts(2)installed to the ceiling,hanging board(3) on the appropriate lpcation,and then use self-tapping screws(4) fixed.

2.Adjust the power cord length well.install the enter the power cord of the lamp onthe terminal (1).

3.Ceiling plate(5) pushed to the top and tighten the locking wire line(6) with screws(7)

4.Finally screwinghe26 light source(8) in lamp holder

Power suooly:AC 110V
50Hz/60Hz
Light source: LED

