


Assembly Instructions

Warnings: You must read this before you proceed.





REMINDER : In the event of unsuitability and you intend to return, please disassemble by reversing the assembly process and where possible pack to fit into its ORIGINAL CARTON BOX.

Table










CAUTION : This table is NOT a TOY.
Keep your child / children at bay in the process of assembly.

Parts List






No.	Picture	Description	Qty
A		Table top	1
B		Legs Support Panels (Long side)	2
C		Legs Support Panels (Short side)	2
D		Table Legs	4

Hardware

No.	Picture	Description	Qty
①		Screws (M8*40MM)	13
②		Nuts	13
③		Springs Washers	13
④		Flat Washers	13
⑤		Spanners	1
⑥		Screwdriver	1
⑦		Leg Leveller(Pre-attached)	5


Assembly Preparation

Before Beginning Assembly:

-  • Read instructions, cover to cover-
-  • Have 2 adults on hand for assembly-
-  • Do not assemble on flooring or carpet-
-  • Assemble on a clean non-marring surface (packing foam)-
-  • Save all packaging until finished-


Assembly Steps

Overview



This Table has multiple parts and may require up to some 30 minutes to assemble. To give you an overview of the 4 parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack all parts.

To avoid any scratch and or damage to the products, place onto a clean flat soft surface.

To the underside of the Table Top(A), there are 4 (four) assembly points.


Insert Screws(1) into these 4 (four) positions with screwdriver(6).

To the legs, there are 2 (two) assembly points on each leg.

Insert Screws(1) into these 8 locations for all 4 (four) legs with screwdriver(6).

TIGHTEN ALL THE SCREWS.

Step 2




Attach the legs to the Table Top(A).

Insert the table legs(D) into the pre-assembled screw from above.

Affix the leg by using Flat Washers(④), Spring Washers(③) and Nuts(②) with Spanner(⑤).

DO NOT OVERTIGHTEN NUTS.

Step 3




This next step is to assemble the leg panels(B&C) to the table legs(D).

Attach the Legs Support Panel(B&C) with Groove End to the Screws(①) on the Legs, and then attach the Legs Support Panel(B&C) without Groove End to the Screws(①) .

Partially tighten Nuts with Flat Washers(④)+Spring Washers(③)+Nuts(②) to the screws(①).

Repeat the same process for all contact points of the Table Legs(D) and the Legs Support Panels(B&C). Once all the Leg Support Panels(B&C) are in place, tighten all nuts in a sequential manner.

Step 4



Turn the table right side up.

Adjust the pre-attached leg leveller(⑦) at the end of each table Leg(D) until the table is level with the ground.










Now go back and inspect all Nuts are tighten in with the Spanner(⑤).

Do this in a sequential manner and make sure every Screw and Nut is tightly turned in.

Your Table is ready for use.

Caution: This Table can only be used on a flat, level surface.

Care & Maintenance

-  Do not put hot items directly on furniture surface
 -  Do not clean furniture with harsh cleansers or polish.
 -  To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -  Children should not climb or jump on the furniture.
 -  Do not write on furniture without a padded barrier to protect the surface.
 -  To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -  Not for commercial use. For residential use only .
 -  Stains may be removed with mild soap solution and damp cloth.
-
-  Dust and pick-up spills using a clean, non-colored, lint-free cloth .

What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity. Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

