




INSTALLATION MANUAL


Model : FCN0770_00
FCN0780_00
Support: [ServiceTeam86@outloo .com](mailto:ServiceTeam86@outloo.com)





* Guests need to prepare their own :




Phillips screwdriver




PARTS







1 X1




2 X1




3 X1




4 X1




5 X1




6 X1




7 X1




8 X1




9 X2




10 X2




11 X2



12 X2




13 X2




35mm

A X24+2




Ø6 X 30mm

B X20+2




Ø15 X 9.5mm

C X24+2




Ø3.5X10mm

D X26+4



Ø4X14

E X2




F X2




Ø5 X 30mm

G X 8+1




Ø20


H X 24+2



J X1




K X1




L=300mm

CL X2




L=300mm

CR X2



L=300mm

DL X2






L=300mm

DR X2

D		X12
CL		X2
CR		X2



1



A		X12
---	---	-----


B		X10
---	---	-----

2




B		X4
---	---	----

3




C		X6
---	---	----

4




5




C		X6
---	---	----


6




D		X2
J		X1

7




A		X4
B		X6

8




C		X4
---	---	----

9




G		X8
K		X1

10



X2


11



X2


A		X8
---	---	----

12




C		X8
---	---	----

13




D		X12
DL		X2
DR		X2
E		X2
F		X2
H		X16


14



15



⚠ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install Anti-tip device provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers. <i>This is a permanent label.</i> <i>Do not remove!</i>
	



SAFETY FIRST, STYLE ALWAYS

Thank you for choosing our products. To ensure safety and performance, please follow these instructions:

- **Assembly:** Carefully follow instructions and tighten all parts.
- **Intended Use:** Use furniture as intended and adhere to weight limits.
- **Handling:** Move gently and check for loose parts regularly.
- **Tipping:** Tall or unstable furniture may tip over if not secured, especially in homes with children or pets.
- **Overloading:** Exceeding weight limits can lead to collapse or damage.
- **Sharp Edges:** Handle furniture with sharp corners carefully, especially around children.

MAINTENANCE & CLEANING TIPS

- **Regular Cleaning:** Use a soft, dry cloth to wipe the surface of cabinet regularly. Avoid harsh chemical cleaners.
- **Protect from Sunlight:** Keep cabinet out of direct sunlight to prevent damage to the material and finish.

DON'T WORRY, WE'VE GOT YOUR BACK.

We don't just sell furniture — we're here for the long haul! If you run into any issues due to manufacturing defects or material problems, we offer a 1-year warranty. That means we'll replace any faulty parts for free — no hassle.

Email: ServiceTeam86@outlook.com