



REMY

Dining Chair

Assembly Guide



IMPORTANT: please read these instructions fully before starting assembly



**SAFETY AND
CARE ADVICE**



NO POWER TOOLS

- Check you have all the components and tools listed
- Remove all fittings from their bags and separate into groups
- We do not recommend use of power tools - this could damage the unit. Only use hand screwdrivers and Allen keys
- Keep children and animals away from the work area, small parts could cause choking if swallowed
- Make sure you have enough space to lay out the parts before starting
- Assemble the item as close to its final position (same room) as possible
- Do not over tighten the nuts to avoid damage to the threads
- Only clean using a damp cloth and mild detergent. Do not use bleach or abrasive cleaners
- Do not allow children to climb or play on this product
- From time to time, check there are no loose screws in this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre
- Unless otherwise stated, this product is designed for domestic use and is not certified for commercial or contract settings.

IMPORTANT INFORMATION



20 Minute
Build




Two Person
Build



Max Weight
Capacity
120kg


Note: Assembly estimates are approximate and can differ based on the specific environment and user experience.

Label	Part Name	Drawing	Size (mm)	Quantity
A	Allen Screw		M6 x 13	4
B	Allen Screw		M6 x 35	8
C	Allen Key		M4	1

Please note, the fixings above are for a single chair.

WHAT'S IN THE BOX

Note: the quantities are the correct amount to complete the assembly. In some cases more fixings may be supplied than are required.

Label	Part Name	Drawing	Quantity
1	Back Rest		1
2	Seat Pad		1
3	Backrest Frame		1
4	Backrest Frame		1
5	Seat Frame		1

Please note, the fixings above are for a single chair.

Note:


- Use a clear, flat surface to avoid bumps or scratches before assembling.
- Insert all fixings loosely at first to allow for alignment; only tighten them once everything is properly positioned, as some adjustment may be required.
- Avoid over-tightening, as this may damage the parts.
- Seek assistance when moving large or heavy parts

STEP 1

Slot 2x Backrest frames
[3+4] into the seat frame
[5]

Secure using 4x Allen
Screw [A]


To allow for alignment,
partially tighten the
fixings with Allen key [C]



NOTE: Insert ALL screws loosely, only fully tighten when instructed to do so. In the event of miss-alignment or chair wobbling, please untighten screws, realign and re-tighten.

STEP 2


Align the seat frame with seat pad [2] and secure using 4x Allen screw [B]. To allow for alignment, partially tighten the fixings with Allen key [C]



STEP 3

Carefully, turn the chair over to stand on the leg frame.

Align the backrest [1] with the top of the seat frame [3+4] and secure using 4x Allen screw [B]. To allow for alignment, partially tighten the fixings with Allen key [C]




STEP 4

Apply weight to the chair to allow the legs to level.
Fully tighten All fixings.

STEP 5

Check the stability.
Your Chair is now ready to use!



STEP 6

Repeat the assembly process for any subsequent chairs.

Please ensure any and all fixings and fittings are FULLY tightened before using this product



our 2 year GUARANTEE

Our products come with a 2 year guarantee, giving you extra peace of mind when shopping with us!

What the guarantee covers



PRE-INSERTED FIXINGS
e.g. loose metal threads



FAULTY JOINTS
e.g. legs bending



EXTERNAL FIXING FAULTS
e.g. metal discs removing
from table top



STRUCTURAL INTEGRITY
e.g. the frame of the
product

Activate your Guarantee

Scan the QR code to read the full guarantee online and register your product. It only takes a moment to fill out.

Or visit: furniturebox.co.uk/our-guarantee

