


KJW.A5082

Assembly Manual

Dual Motors Recliner with Headrest









CAUTION

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.


PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Count parts before assembling.

A 1pc 	B 1pc 	C 1pc 
Backrest	Seat	Left Wing
D 1pc 	E 1pc 	F 2pcs 
Right Wing	Power Supply	Cup holder


Step 1

Cut the plastic ties to remove the hardware pack (Includes: Power Supply (E) and Cup holders (F)). Locate the Left Wing (C) and Right Wing (D) at the bottom of the Seat (B), then take them out.




Step 2

Zip up the Backrest (A) and the Seat (B) together.




Step 3

Slide the Backrest (A) into the metallic quick connectors of the Seat (B). Push down the Backrest (A) firmly until each side is locked into place and an audible “click” is heard.




Step 4

Slide the Left Wing (C) and Right Wing (D) into the Backrest (A).




Step 5

Connect the Headrest cable into the Headrest cable. Locate the Power Supply (E) and connect to its corresponding receiver on the base of the Seat (B).



Step 6

Attach the back cover to the bottom of the Seat (B) with Velcro.




Step 7

Open the front side of the armrest and install the cup holder (F) .


Attention: When installing the cup holder, please make sure to push it all the way in with force. When the cup holder is in a loose state, it may get stuck in the front baffle, causing the armrest to fail to open and close properly.

Then open it when you need to use it and close it when you don't.



Step 8

Plug the Power Supply (E) into the power outlet. (The indicator light will turn green when the power is connected, and it will go out a few seconds after the power is disconnected.)



Step 9

Now the recliner is ready for relax. Then you can start your adjustment of the recliner by keys outside the arm.

