


ASSEMBLY INSTRUCTIONS

Corner+Armless chair



+ Do Not Use Power Tools



+ Suggested Adults



NOTE

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- part # - Corner base
- part # - Corner cushion
- part # - Armless chair base
- part # - Armless chair cushion
- part # - Chrome leg
- part # - Gold leg

Do not assemble if any of the following Hardware parts are missing:


- part # - Allen wrench
- part # - Bolt M8"*35mm
- part # - Washer M8*16mm
- part # - Connect metal plate

2 IMPORTANT ASSEMBLY INFORMATION



Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included



- ① Corner base 1pc
- ② Corner cushion 1pc



- ③ Armless chair base 1pc
- ④ Armless chair cushion 1pc



- ⑤ Chrome leg 8 pcs
- ⑥ Gold leg 8 pcs



+ Hardware Included

- A** Allen wrench 1 pc
- B** Bolt M8"*35mm 24pcs



- C** Washer M8*16mm 24 pcs
- D** Connect metal plate 100*75*18mm 2 pcs

