

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE









* Please make sure that you have all parts indicated before you begin assembly of this item


* This item should be assembled on a soft surface to prevent scratching the finish during assembly

* This item may require periodic tightening

Parts List and Hardware List

Product Dimensions: 58.27" W x 27.95" D x 27.56" H

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Back		1X
C	Arm		2X
D	Leg		4X
H1	Allen bolt		22X
H2	Spring washer		22X
H3	Flat washer		22X
H4	Allen key		1X



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 50 minutes.

Tools Required for Assembly (included): Allen Key

