


Kitchen Island Cart

Assembly Instructions - Please keep for future reference

N707P404588 / N707P404589



Important - Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions

To help prevent product toppling over please follow the below steps:-




















Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.

HARDWARE BOX INSIDE BOX 2

1  CAM BOLT QTY: 36	2  CAM LOCK QTY: 36	3  WOOD DOWEL Ø6*25mm QTY: 28
4  BALL BEARING GLIDE QTY: 6	5  BALL BEARING GLIDE QTY: 6	6  FLAT HEAD SCREW Ø6*12mm QTY: 36
7  BOLT 1/4"*32mm QTY: 6	8  SPRING WASHER QTY: 6	9  FLAT WASHER QTY: 6
10  FLAT HEAD SCREW Ø6*25mm QTY: 12	11  HANDLE QTY: 7	12  BOLT Ø8*12mm QTY: 14
13  HINGES QTY: 8	14  FLAT HEAD SCREW Ø7*15mm QTY: 90	15  HINGES QTY: 7
16  SHELF PIN QTY: 12	17  ROUND HEAD SCREW Ø7*15mm QTY: 8	18  CASTER QTY: 4
19  FLAT HEAD SCREW Ø8*25mm QTY: 6	20  CAMTOOL QTY: 1	
21  ALLEN KEY QTY: 1	22  SPING BALL LATCH QTY: 2	23  BOLT Ø1/4*12mm QTY: 16


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.

4





Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación, déjelo a un lado hasta que sea necesario.

Les glissières doivent être séparées avant l'assemblage.
Après la séparation, mettez de côté jusqu'au moment de l'assemblage.


Pay attention when connecting !
The sliding module must be at the front end.

STEP 1 : Extend Slide
Extender la diapositiva






STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier

Push lever for the left of drawer ,
press the lever for the right of drawer.



STEP 3: Remove Runner
Quitar el corredor
Enever le coureur


Tool required




Assembly Instructions

BOX 1 : N707P404588


C_L



C_R



F



LEFT FRAME

QTY: 1


RIGHT FRAME

QTY: 1


FRONT PANEL - LEFT

QTY: 1


G



H



I



FRONT PANEL - RIGHT

QTY: 1


FRONT PANEL - MIDDLE

QTY: 1


BRACKET - LEFT

QTY: 1


J



K



L



BRACKET - RIGHT

QTY: 1


BRACKET - LEFT

QTY: 1


BRACKET - RIGHT

QTY: 1


M



P



Q



BRACKET BOTTOM

QTY: 1


MIDDLE SHELF

QTY: 1


LEFT/RIGHT SHELF

QTY: 2


S



T



V



DRAWER FRONT

QTY: 1

DRAWER BACK





QTY: 1

DRAWER FRONT

QTY: 2

Assembly Instructions


BOX 1 : N707P404588

Y_L 	Y_R 	AA 
DRAWER LEFT QTY: 3	DRAWER RIGHT QTY: 3	EXTENDED SUPPORT QTY: 1
BB 		
EXTENDED SUPPORT QTY: 1		

Assembly Instructions

BOX 2 : N707P404589


A



TOP PANEL

QTY: 1


B



EXTENDED TOP PANEL

QTY: 1


DL



CENTER PANEL - LEFT

QTY: 1


DR



CENTER PANEL - RIGHT

QTY: 1


E



BOTTOM PANEL

QTY: 1


N



PULL BAR

QTY: 4


O



BACK PANEL

QTY: 1


RL



LEFT DOOR

QTY: 2


RR



RIGHT DOOR

QTY: 2


U



DRAWER BOTTOM

QTY: 1


W



DRAWER BACK

QTY: 2


X



DRAWER BOTTOM

QTY: 2

Z





DOOR STOP

QTY: 3

Assembly Instructions


STEP 1




1		2PCS
4		2PCS
6		6PCS

Assembly Instructions

STEP 2




STEP 3



Assembly Instructions


STEP 4




2		6PCS
3		6PCS
19		6PCS
20		1PC

Assembly Instructions

STEP 5




STEP 6




2		8PCS
20		1PC

Assembly Instructions

STEP 7




STEP 8




Assembly Instructions

STEP 9





5		6PCS
6		18PCS

STEP 10





1		12PCS
---	--	-------

STEP 11



2		8PCS
10		8PCS
11		2PCS
12		4PCS

STEP 12




2		4PCS
10		4PCS
11		1PCS
12		2PCS


X2

Assembly Instructions

STEP 13




STEP 14



16  12PCS


STEP 15



11		4PCS
12		8PCS
13		8PCS
14		48PCS


Assembly Instructions

STEP 16



14		24PCS
15		4PCS
22		2PCS


STEP 17




14		18PCS
15		3PCS

Assembly Instructions

Finish!



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

