

Assembly Instructions

HAKON LB OFFICE CHAIR



A (1pc)



B (1pc)



C (2pcs)



D (1pc)



E (1pc)



F (5pcs)



G (1pc)



H (6pcs)
M6x35mm



I (4pcs)
M6x20mm



J (3pcs)
M8x45mm




K (4pcs)
M6




L (1pc)
#5

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.


1




2




3



4



5



6



During assembly, hand tighten screws only. When the screws are in place, tighten completely.


Assembly Instructions HAKON LB OFFICE CHAIR

Function Description




PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer.


① Chair Height Adjustable



② Chair Tilt and Lock



③ Tilt Tension



During assembly, hand tighten screws only. When the screws are in place, tighten completely.