



ODIFORGO

Electric Salt and Pepper Grinder Set




Parts Identification


A




C




B



D



E



A. Grinder body

B. Type-C charging cable


C. Base

D. Small silo(50ml / 1.69oz)

E. Small silo(50ml / 1.69oz)

Usage Guide

Install the spice bin, align the grinder with the spice bin you want to use, and press down gently to lock the spice bin.



Small silo can grind:

Coarse Salt	Peppercorns
Cumin Seeds	Sichuan Pepper
Fennel Seeds	Coriander Seeds
Sesame Seeds	Mustard Seeds
Toasted Garlic	Cacao Nibs

..... And more


Large silo (Optional) can grind:

Coarse Salt	Peppercorns
Cumin Seeds	Sichuan Pepper
Fennel Seeds	Coriander Seeds
Sesame Seeds	Mustard Seeds
Toasted Garlic	Cacao Nibs

..... And more

Adding Spices and Adjusting the Coarseness

Unscrew the spice compartment and add the spices you need filling it about 2/3 full. Tighten the base clockwise.




There is a knob at the bottom of the spice jar to adjust the coarseness of the spice.

Before adjusting the coarseness, ensure that the silo and the grinder are connected, then turn the knob according to the prompts at the bottom.

Tighten it as much as possible based on the prompts to get the smallest particles. If you want larger particles, simply adjust it in the opposite direction.

Note: It is not a fixed gear, but an adjustable tightness.



Important Safety Measures

Please read the following instructions carefully before using the device.

Important: Persons (including children) who cannot use the device safely due to physical, sensory, or mental impairment must not use the device unless they are supervised by a person responsible for safety.

- Check the device regularly for damage. If the device shows any signs of damage, stop using it immediately.
- Do not immerse the device in water or other liquids.
- When cleaning or maintaining the device, or pouring food in or out, do not press the switch to prevent the device from being powered on and causing danger.
- While the equipment is running, do not touch the rotating grinding head.
- Do not operate in an environment with explosive or flammable fumes.
- Do not incinerate the device even if it is severely damaged, as the batteries contained inside may explode during combustion.
- Before an electrical appliance is disposed of, the battery should be removed and the power supply should be cut off before removing the battery.
- Remove used batteries and dispose of them properly, recycling them at designated points.

Cleaning and Maintenance Precautions

- Do not press the power button during maintenance and cleaning, and make sure the machine is turned off and not in operation.
- Do not use metal brushes, volatile oil, gasoline, rosin oil, sulfuric acid, etc. to clean the surface of metal, plastic, and other parts.
- Do not immerse the machine directly in water for cleaning, or allow water to seep into the interior of the machine, as this may cause machine failure and lead to potential safety hazards.

Charging the Device

- Connect the other end of the USB cable to the charging socket, hold one end of the USB cable and insert it horizontally into the top opening of the motor.
- When the white indicator light turns on, it means the grinder is currently charging.
- Charging takes about 2 to 4 hours.
- When the white indicator light stops flashing, charging is complete.

After-sales Service

Dear customer, thank you for purchasing our electric salt and pepper grinder! We are committed to providing you with high-quality products and excellent after-sales service. If you have any questions, please feel free to contact us and we will reply you within 24 hours.