


Glider Chair



⚠ WARNING: READ ALL WARNING & SAFETY INSTRUCTIONS BEFORE ASSEMBLING CRIB. KEEP INSTRUCTIONS FOR FUTURE USE.

First remove hardware from box and sort by size. Check to see that all hardware and wooden pieces are present before assembling. Follow instructions listed below in the proper sequence as numbered to assure fast, easy and correct assembly.

⚠ WARNING!

1. DO NOT attempt to repair or modify parts with cracks or defects. Please contact us for immediate replacement.
2. This product is for home use and is not intended for use in schools, day care centers or other commercial establishments.
3. Must be assembled by a capable adult.

◆PARTS IDENTIFICATION


A. BASE (1PC) 	B. BACK FRAME (1PC) 	C. ARM (2PCS) 	D. ARM CUSHION (2PCS)
E. BACK CUSHION (1PC) 	F. SEAT CUSHION (1PC) 	G. OTTOMAN (1PC) 	H. PILLOW (1PC)

◆HARDWARE


1. Screw 50mm x width (2 pcs) 	2. Screw 35mm x width (6 pcs) 	3. Spring washer (8 pcs)
4. Barrel Nut length x width(2 pcs) 	5. Wrench (1 pcs) 	

CHAIR ASSEMBLY SHEET


1



2




3




CHAIR ASSEMBLY SHEET


4



5



6



KEEP INSTRUCTIONS FOR FUTURE USE

Nothing compares to the comfort of an glider rocker . The easy gliding action is designed for ultimate relaxation . The design and engineering of our products are developed jointly to guarantee optimum comfort, superior quality and an excellent quality/price ratio.

WARRANTY

products are guaranteed free of factory defects for a period of one month from the date of purchase. Please keep your original receipt so that we may process your warranty request.

Tips for cleaning:

The finish on rockers is non-toxic and exceptionally durable. To preserve the condition of the original finish, occasionally clean the product with a soft damp cloth. Fabrics should dry-clean only to maintain optimum condition. Re-tighten the eight bolts of the ball bearing system periodically with a ratchet and a socket of 1/2" (13mm).

One month limited warranty

We want you to be satisfied with any product that bears the name or logo. We will provide promptly, at the request of the retailer, and without charge, any missing parts that have been reported, with proper description, within 7 days of the purchase of the products. Our warranty guarantees optimal workmanship and lack of significant defects. The product's warranty lasts three months from the date of your purchase. Please keep the original receipt so that, if necessary, we may process your three months limited warranty request. This warranty only covers new units with original packaging. Ownership of the warranty is non-transferable. The warranty does not cover any used, secondhand or demo models. Our obligation under this warranty is to replace or repair the merchandise, at our option, free of charge. This warranty does not cover any damaged or defective parts that result from normal wear and tear, abuse, negligence, improper use or alteration to the finish design or hardware. Specific rights issued by this warranty may vary from state to state. Some states do not allow limitations on how long implied warranties last. **DO NOT** return products to the store once a product is used as it cannot be resold and the materials and energy invested in the product would go to waste. In the event that determines that a defect resulted from customer abuse or misuse, we will contact you with information about services and methods to prevent occurrences. We strongly recommend you register your product with our company by filling out the registration provided and mailing it back to us. This ensures you are up-to-date with our products in the event of a recall.

This warranty does not cover damage caused by accident, misuse or any use other than as intended and described in this assembly sheet or damage resulting from failure to maintain and clean this product as specified in this assembly sheet. This warranty applies only to the original purchaser of the company.
