

Assembly Directions for 28" & 33" Square Tables


in Garden Classic Collection

#GCT0028D, #GCT0028C, #GCT0028B

#GCT0033D, #GCT0033C, #GCT0033B



Garden Classic Table



PACKAGE CONTENTS


- 1 Top
- 2 Bases
- 1 Cross Support
- 2 Footrests (Bar and Counter Height Only)
- 1 Hardware Package

TOOLS NEEDED:


- Hammer
- $\frac{7}{16}$ " Wrench
- Cordless Drill/Screwdriver
- Allen Wrench (Included)

HARDWARE PACKAGE


- 8 $\frac{1}{4}$ " x 2" Allen Head Bolts
- 8 $\frac{1}{4}$ " Flange Nuts
- 16 3" Screws (8 if Dining Height)
- 2 Umbrella Knobs
- 1 Allen Wrench



STEP #1 - Fasten the first base to the aluminum frame of the top using 4- 1/4" x 2" Allen Head bolts.



STEP #2 - First fasten the cross support to the base using 3" screws. Second fasten the two footrests to the upright using 3" screws. (Bar and Counter height only.)



STEP #3 - First fasten the second base to the aluminum frame of the top using 4- 1/4" x 2" Allen Head bolts. Second fasten the cross support and footrests to the base using 3" screws.



Your Table is complete!