








(1)x1	(2)x1	(3)x1 (L)x1 (R)
 Back Cushion	 Seat Cushion	 Left-Arm Right-Arm
(4)x1	(5)x1	(6)x1
 Part: Mechanism	 Gas Lift W/ Cover	 Base
(7)x5	Please unscrew all screws from cushion before assembly. (A)x8  M6X30 ARM SCREW (B)x4  M8X22 MECHANISM SCREW (C)x4  M8X30 L-BAR SCREW	
 Caster		



It is important to assemble all parts so that the directional "Arrows" point in the same direction. Make certain that all screws are **FULLY** tightened before using the chair. Each month, check all screws and tighten any that may have loosened.

