


Owner Manual



MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :

This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
200 LBS



Installation:
30 minutes.



Two Person



Before You Start

Please follow the steps below:

-  Unbox the package and check if all parts and accessories are complete.
-  If you find something missing, stop assembly and contact your supplier immediately.
-  Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
-  NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty

-  We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
-  Are you having difficulty with assembly? Missing parts? Please send email with your order number
-  For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.


Exploded Diagram

Please confirm that you have received all the parts in the box and start the installation.




Note:

The handle has been pre-installed in the drawer.
Please remove it before installation.




Parts List

A ×1



Cabinet body

B ×2




Connection plate

C ×4



Leg


D ×2



Leg extender


Hardware List

1 ×4




Anti-tip component

2 ×4




Self-tapping screw
D4x20mm

3 ×2




Hardware pack

4 ×4




Expansion pipe
L30mm

5 ×4



Self-tapping screw
D4x40mm

6 ×1




Screwdriver

7 ×1




Hexagonal socket wrench
M5

8 ×12




Screw rod
M8x30mm

9 ×12



Screw rod
M8x40mm

10 ×4+1



Wooden dowel
Ø8x30mm

11 ×24+2




Flat gasket
M8

ASSEMBLY INSTRUCTIONS

Step 01

1. Insert the wooden dowel (10) into the corresponding holes of the leg (C) and the leg puller (D).
2. Pass the screw (9) through the flat washer (11), then through the leg puller (D) and the leg (C) to assemble them, and lock it with an internal hexagonal wrench (7).


10	 x 4	Ø8x30mm	9	 x 4	M8x40mm
11	 x4	M8	7	 x 1	M5



Step 02

Pass the screw (9) through the flat washer (11), through the connecting plate (B) and the leg (C) to assemble them, and then lock it with an internal hexagonal wrench (7).


9	 x 8	M8x40mm	11	 x 8	M8
7	 x 1	M5			



Step 03


Pass the screw (8) through the flat washer (11), through the connecting plate (B) and the cabinet body (A) to assemble them, and then lock it with an internal hexagonal wrench (7).

8	 x 12	M8x30mm	11	 x 12	M8
7	 x 1	M5			




Step 04


Hold the rope with your hand and slowly pull the drawer out in the direction indicated by the arrow.



Step 05


Use the screwdriver (6) to loosen the installed drawer handle screws in the direction indicated by the arrow.


6		x 1	Screwdriver
---	---	-----	-------------



Step 06





Use the screwdriver (6) to insert the handle screws through the drawer panel and the handle to assemble them together.

6		x 1	Screwdriver
---	---	-----	-------------



Step 07


NOT PROVIDED




Note:
Before the next step, adjust the feet of
the locker to keep it level.

Step 08


Pass screw (2) through the anti-fall part (1) and insert it behind the panel, then tighten with screwdriver(6).



2	 x 4	D4x20mm	6	 x 1	Screwdriver
1	 x 2	Anti-tip component			




Step 09

Install Anti-tip device (1) to the wall in this step.


5	 x 4	D4x40mm	6	 x 1	Screwdriver
1	 x 2	Anti-tip component	4	 x 4	L30mm



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device 1 to the wall with screws 5.

Step 10

⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER exceed the maximum size and weight of the TV shown in the instructions.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***

3



x 2

Hardware pack

