


# **Assembly Instructions**

## **Hanging Chair**










**▲ WARNING:**








**Thank you for purchasing Please read below before you proceed.**

- 1. Not intended for use by children 12 years of age or younger.**
- 2. This is a hanging chair, not a swing chair.**
- 3. The hanging chair should be installed no more than 20" above ground.**
- 4. The hanging chair should be installed at a minimum of 4-5 feet away from the walls.**
- 5. The hanging chair should have a minimum clearance of 30" from any obstacles.**
- 6. Do not swing on or in the chair. It could cause the product to tip over, resulting in possible injury.**
- 7. This chair basket is not a toy.**
- 8. No mounting hardware kit included.**
- 9. Professional installation required.**

## **Parts List**

No.	Picture	Description	Qty
A		Top	1
B		Left Back	1
C		Right Back	1
D		Seat	1
E		Back Cushion	1
F		Seat Cushion	1
G		Long Chain (8 ft.) with Carabiners	1

## **Hardware**

①		Bolt (M6x40mm)	16
②		Washer	31
③		Nut	16
④		Bolt Cap	16
⑤		Nut Cap	16
⑥		Spanner	1
⑦		Allen Key	1



- Read the instructions before you start the assembly.



- May need assistance for assembly.




- Assemble on a clean and smooth surface.



- Save all package until finished.


## Assembly Steps

### Overview




This Basket has multiple parts and may require up to 30 minutes to assemble. The above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarize yourself with the parts and steps before assembly.

## **Step 1**



Unpack and place all parts on a clean, soft surface.

## **Step 2**




Place the Left Back(B) and Right Back(C) on a clean, non-marring surface.

Note: Find the sticker with the words "upper side" on them, and keep all the upper sides upwards.

Attach Left Back(B) to Right Back(C) using Bolts(1), and Washers(2) and Bolt cap(4) on one side and Washers(2) and Nuts(3) and Nut Cap (5) on the other side, with Allen Key(7) and Spanner(6).

Do not fully tighten the Bolts.


## **Step 3**



Align Left Back(B), Right Back(C) and Seat(D).

Attach Left Back(B) and Right Back(C) to Seat(D) using Bolts(1), and Washers(2) and Bolt cap(4) on the upper side and Washers(2) and Nuts(3) and Nut Cap (5) on the lower side, with Allen Key(7) and Spanner(6).

## Step 4



Align Left Back(B), Right Back(C) and Top(A).

Attach Left Back(B) and Right Back(C) to Top(A) using Bolts(①), and Washers(②) and Bolt cap(④) on the upper side and Washers(②) and Nuts(③) and Nut Cap (⑤) on the lower side, with Allen Key(⑦) and Spanner(⑥).


**All the screw must be tighten now.**

## Step 5




Fully tighten all nuts

## Step 6












**Put Cushion(E)and (F)**

## **Step 7**



Install 8ft chain with 2 Carabineers (G) to the basket, your hanging chair is ready for next step.

## **Care & Maintenance**

-  • Do not put hot items directly on furniture surface.
-  • Do not clean furniture with harsh cleansers or polish.
-  • To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-  • Children should not climb or jump on the furniture.
-  • To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-  • Not for commercial use. For residential use only.
-  • Stains may be removed with mild soap solution and damp cloth.
-  • Keep away from sources of ignition
-  • Dust and Pick-up spills: Use a Clean, non-colored, lint free cloth.