


USER MANUAL




ARMOIRE WARDROBE CLOSET
WITH DRAWERS

Model: JY-260130


TOOLS REQUIRED




Phillips screwdriver
(Not included)



Hammer
(Not included)



Drill
(Not included)



Protective blanket
(Not included)



ATTENTION


Keep children and pets away while assembling.




How to use cam locks

CAM LOCK FASTENING SYSTEM


This Cam Lock Fastening System will be used throughout the assembly process.




1




2



3



4



INTRODUCTION

Thank you for choosing our products. Please read the instructions carefully and keep them for future reference. If you need further assistance, please contact our customer service online via email.


PRECAUTIONS


1. When installing the product, use a soft underlay (such as carpet or cardboard) to avoid scratching or damaging the surface of the product.
2. Please try to use a manual screwdriver instead of electric screw driver. A manual screwdriver can be used to better control the tightness of the screws.
3. Do not use any glue.
4. The product is unstable before it is assembled. Please pay attention to the product installation sequence.
5. The structure of this product can not meet the requirements of the placement of heavy items and children climbing.

WARRANTY

We provides an **18 Month** Warranty on all products starting from the date of original purchase. If the product has any manufacturing defect, please contact customer service via email with your order number and other details to the problem. We will send you further information about the return or exchange.



















PACKAGE CONTAINS






















x3

HARDWARES LIST

A x140  M6*40mm	B x140  M15*11mm	C x162  M3.5*14mm	D x46  M5*40mm
E x8  	F x28  M8*40mm	G x4  M8*60mm	H x6  H1 H2
J x4  	K x2  	L x3  	
M x18  M3.5*14mm	N x16  	P x20  	Q x10  M4*20mm
R x18  M3*12mm	S  S1  S2  S3  S4  S5		T x71  T1  T2 M3*16mm
U x80  	V x1  V1  V2	W x6  M4*10mm	Y x1  Y1  Y2


















PARTS LIST » A BOX

Unit: (mm)

① x1  1201*480*15 mm	③ x1  1003*480*15 mm	④ x1  1003*480*15 mm
⑪ x1  1201*480*15 mm	⑫ x2  700*380*15 mm	⑬ x1  768*80*15 mm
⑳ x1  385*80*3 mm	㉑ x2  469*776*3 mm	㉒ x1  768*80*15 mm
㉓ x2  776*311*3 mm	㉔ x1  931*393*3 mm	㉕ x1  385*438*12 mm
㉖ x1  1200*480*15 mm	㉗ x2  308*391*3 mm	㉘ x1  308*778*3 mm
㉙ x1  768*80*15 mm	㉚ x4  375*378*15 mm	

















PARTS LIST » B BOX

Unit: (mm)


⑤ x1  1003*480*15 mm	⑥ x1  1003*480*15 mm	⑧ x1  767*480*15 mm
⑫ x1  401*480*15 mm	⑮ x1  385*80*15 mm	⑯ x3  385*80*15 mm
⑰ x3  320*120*12 mm	⑱ x1  320*120*12 mm	⑳ x3  768*80*15 mm
㉓ x3  764*220*15 mm	㉔ x3  999*380*15 mm	㉗ x1  768*80*15 mm
㉙ x1  999*380*15 mm	㉛ x1  385*80*15 mm	㉝ x2  385*80*15 mm
㉞ x1  385*80*15 mm	㉟ x1  400*480*15 mm	

PARTS LIST » C BOX


Unit: (mm)

② x1  401*480*15 mm	⑦ x1  767*480*15 mm	⑨ x1  767*480*15 mm
⑪ x1  767*480*15 mm	⑬ x2  385*438*12 mm	⑭ x1  385*480*12 mm
⑱ x2  320*120*12 mm	⑲ x3  720*120*12 mm	⑳ x3  728*314*3 mm
㉑ x3  306*60*12 mm	㉓ x2  553*393*3 mm	㉔ x1  380*479*15 mm
㉕ x1  380*479*15 mm	㉗ x1  380*479*15 mm	㉘ x1  380*479*15 mm
㉙ x1  383*80*3 mm		

INSTALLATION INSTRUCTION



$$L = CR + DR + CL + DL$$



01

C x18pcs




M3.5*14mm




L x3pcs



CL



CR




02

A x8pcs




M6*40mm

E x2pcs



03

A x2pcs




M6*40mm

B x2pcs



M15*11mm



x2


04

A x8pcs





M6*40mm


E x2pcs




05




06




07




B x8



08



A x10




09


B x10pcs





M15*11mm



10



11




12

B x10pcs





M15*11mm

E x2pcs





E x2





B x10


13





14





15





16





17



18



19



20

B x2pcs




M15*11mm

C x2pcs



M3.5*14mm


H x1pc



C x2



H1 x1

12





B x2



21





22





23





24





25





26





27





28





29





30




31






32








34





36





A x8pcs



M6*40mm

F x2pcs



M8*40mm

C x2pcs



M3.5*14mm



H x1pc





H1





H2





39



40



41



42

D x4pcs



M5*40mm

G x2pcs




M8*60mm

C x4pcs



M3.5*14mm


H x1pc





H1





H2





43







44





45









48








50

B x2pcs







M15*11mm








52











55





56




57




58



59




D x2



60



K x2pcs






M x16pcs






M3.5*14mm



61



62



63

C x16pcs



M3.5*14mm

P x8pcs





N x4pcs



Q x4pcs



M4*20mm



x4

64

C x12pcs



M3.5*14mm

P x6pcs





N x3pcs



Q x3pcs



M4*20mm



x3

65

C x4pcs



M3.5*14mm

P x2pcs





N x1pc



Q x1pc



M4*20mm



x1

66

C x8pcs



M3.5*14mm

P x4pcs





N x2pcs



Q x2pcs



M4*20mm





x2

67

C x80pcs

















M3.5*14mm





The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.


Obvious gaps between doors or Doors don't look closed  Have gap	1 Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little. Top  Turn right Bottom  Turn right The left door  Top  Turn right Bottom  Turn right The right door  * If the 2 doors are overlap, please turn the "internal & external screw" to the left.		
When door is crooked  Have gap	1 Rotate the "front and rear screws to the left. Top  Turn left Bottom  Turn left *After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.	2 Push the door to the cabinet. 	3 Rotate the "front and rear screws to the right. Top  Turn right Bottom  Turn right
When door is leaning  Overlap Protruding to the underside	Turn "internal & external screw" to the left can make the top of the door tilted outward. Top  Turn left Bottom  Turn left 	Protruding to the upside  Overlap	Turn "internal & external screw" to the left can make the bottom of the door tilted outward. Top  Turn left Bottom  Turn left 
When the door is higher on top  Have gap	1 Turn "up & down screw" to the left. Top  Turn left Bottom  Turn left	2 Lower the door's height so that 2 doors are of the same height. 	3 Turn "up & down screw" to the right. Top  Turn right Bottom  Turn right *If the door is lower on bottom, please lift up the left door slightly on step 2.

68



x3

69




x3

70

A x18pcs



M6*40mm




x3

71

B x18pcs



M15*11mm



x3

72


N x6pcs



W x6pcs




M4*10mm



x3

73

L x3pcs



DR




DL




R x18pcs



M3*12mm






x3







75

U x80pcs



76



Mandatory!

For safety reasons, we strongly recommend you follow these instructions to install the anti-tipping hardware, when installed properly, this hardware may prevent the unit from tipping unexpectedly.


⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER open more than one drawer at a time.
- NEVER put a TV on this product.
- Place heaviest items in the lowest drawers.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.



This is a permanent label. Do not remove!



78

