

Parts List				
Label	Picture	Description	QTY	
A		Table Top	1	
В		Leg	4	
Hardware				
Label	Picture	Description	QTY	
1)		Bolt (M <mark>8</mark> x50 mm)	9	
2	\bigcirc	Washer (M8.5/16x2mm)	9	
3		Spring Washer (M8.5/11x1mm)	9	
(4)		Allen Key	1	



with the parts and steps before assembly.





EXERT pressure, floorwards, onto the Table.

This pressure will help the Legs and Table Top reach alignment at all joints. Check for wobbles.

In a sequential manner, gradually tighten all Bolts until evenly secured.

Inspect the Table and make sure all parts are adequately connected.

Please use adjustable foot for uneven floors.

Your Table is ready for use.

This Table can only be used on a flat, level surface.

Care & Maintenance		
● Do not clean furniture with harsh cleansers or polish.		
 To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended. 		
 Children should not climb or jump on the furniture. 		
◎ ∠ ● Do not write on furniture without a padded barrier to protect the surface.		
 To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings. 		
Not for commercial use. For residential use only.		
Stains may be removed with mild soap solution and damp cloth.		
Dust and pick-up spills using a clean, non-colored, lint-free cloth.		