











Installation manual




Code	Dimensions				Package
001	1258	364	22	1	1/1
002	1186	334	16	1	1/1
003	359	395	16	2	1/1
005	396	313	16	1	1/1
006	396	313	16	1	1/1
007	390	311	16	1	1/1
008	1186	60	16	2	1/1
010	472	360	16/32	1	1/1
011	472	360	16/32	1	1/1
012	1186	70	30	1	1/1
013	415	1203	3	1	1/1
accessories				1	1/1




x4 e1 Ø 7x50mm 	x12 r1 Ø 15x12mm 	x12 r16 	x32 f1 Ø 8x30mm 
x4 a143 	x4 b119 	x14 p25 Ø 3,5x16n 	x4 d1 Ø 5x17 mm 
x6 l2 	x6 k1 	x1 z1 	




1




2




3




4




5



6





A diagram showing a crystal face with Miller index (007). A thick black arrow points from the face to a distance d_1 .

