


# User Manual












## Accent Chairs











# ASSEMBLY INSTRUCTION


Thank you for purchasing this product. Please take time to read and follow the instructions below. Check that you have all parts and hardware before assembly. Parts apparently missing are often found in the packing materials. If you do not have all the parts listed, have your dealer contact us and they will be sent to you immediately.

## Parts List






Label	Picture	Description	QTY
①		Backrest	1pcs
②		Seat	1pcs
③		Front foot	2pcs
④		Right back foot	1pcs
⑤		Left back foot	1pcs
⑥		Cross bar	1pcs
⑦		Right arm	1pcs
⑧		Left arm	1pcs
⑨		Right handrail post	1pcs
⑩		Left handrail post	1pcs
⑪		Bracing piece	1pcs




# Hardware

Label	Picture	Description	QTY
(A)		Bolt 5/16*45mm	27+1pcs
(B)		Spring Washer	21+1pcs
(C)		Washer	21+1pcs
(D)		Wood Dowel	2+1pcs
(E)		Rubber plug	4+1pcs
(F)		Allen Key (5/16)	1pc
(G)		Allen Key (1/4)	1pc
(H)		1/4*20mm	2pcs




# STEP#1

- (A)  \*4
- (B)  \*4
- (C)  \*4
- (G)  \*1
- (H)  \*2







## STEP#2

- (A)  \*4
- (E)  \*4







## STEP#3

- (A)  \*7
- (B)  \*7
- (C)  \*7








# STEP#4

- (A)  \*4
- (B)  \*4
- (C)  \*4



# STEP#5


- (A)  \*8
- (B)  \*6
- (C)  \*6
- (D)  \*2



Assembly of handrail

## STEP#6

When the chair is assembled,  
if you find uneven feet,  
twist the studs on the back  
feet until the chair is balanced.



# WARRANTY CARD

## Your warranty includes

- **30 Days Money Back Guaranty**

Within the first 30 days of your purchase, you are allowed to return your product for a full refund.

- **30 Days to 3 Months(6 Months)**

We will replace the defective unit due to manufacturer fault with a new one. (You will receive extra 3 Months warranty if you register on our website.)

- **3 Months to 24 Months**

Within 24 Months, we will provide timely and effective online after-sales service after your purchase.