
IMITATION RATTAN CEILING FAN WITH LIGHT

## INSTALLATION AND OPERATING INSTRUCTIONS

# USER INSTALLATION MANUAL




**WARNING: SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER**

## THANK YOU FOR YOUR PURCHASE

Thank you for purchasing this quality product. To ensure correct function and safety, please read and save all instructions before using the product .

# PARTS & ACCESSORIES

## Ceiling Fan Kit:




Fan body *1

## Remote Control Kit:




Remote control *1

## Installation Kit:




Expansion Bolts *4



Plastic anchor *4



Self-tapping screws *4



Screws *2



Wiring cap *4



Gloves * 1

# SAFETY TIPS BEFORE INSTALL

1. To avoid the risk of electric shock, turn off the electricity at the main fuse box or circuit panel before beginning the fan installing or fan servicing or accessories installing, ensure that the electricity remains off during the entire installation or servicing process.

2. Read all instructions and safety information carefully before installing your fan and save these instructions.

3. Ensure that all electrical connections comply with local codes, ordinances, and the National Electrical Code. If you are not familiar with electrical wiring, it is recommended to hire a qualified and licensed electrician.

4. **WARNING:** To reduce the risk of fire, electric shock, or personal injury, install to an outlet box marked "Acceptable Fan Support" and use the mounting screws included with the outlet box. Most outlet boxes commonly used to support lighting fixtures do not. included. That's acceptable for fan support and may need to be replaced. If in doubt, consult a qualified electrician.

5. Use UL-listed general-use switches for the installation. Refer to the instructions provided with the light kits for proper assembly.

6. Once the installation is complete, carefully check that all connections are securely tightened.

7. After making the electrical connections, position spliced conductors facing upwards and carefully insert them into the outlet box. Make sure to separate the wires, with the grounded conductor and the equipment-grounding conductor positioned on one side of the outlet box.

8. **WARNING:** To reduce the risk of electric shock and fire, do not use this fan with any solid state fan speed control device or rheostat.

9. Wait until the fan comes to a complete stop before separating the reverse switch.

10. Never insert objects into the fan blades while they are in motion.

11. Take caution when working near or cleaning the fan to prevent personal injury or damage to the fan and other items.

12. Avoid using water or detergent to clean the fan or fan blades. Instead, use a dry dust cloth or a lightly dampened cloth for most cleaning purposes.

**NOTE:** The manual's safety precautions and instructions provided here are not exhaustive and may not address all potential conditions and situations. It is important to exercise common sense and caution during the installation and operation of this fan.

**NOTE:** It is essential to supervise children to prevent them from using the appliance as a toy.


**NOTE:** This product is not intended for use by individuals (including children) with physical, sensory, or mental limitations or impairments unless they are supervised or trained by a responsible person who ensures their safety.

**WARNING:** To reduce the risk of personal injury, do not bend the blade holder (also called the "flange") during assembly or after installation. Do not insert objects in the path of the blade.


**WARNING:** To reduce the risk of fire or electric shock this fan is NOT suitable for use with solid-state speed controls.

# PRE-INSTALLATION

## Tool preparation




Phillips screwdriver
(Longer than 8 inch)




Step ladder



Wire stripper




Electrical tape




Drill

## Power off




**Before installation, the power must be turned off to prevent electric shock**


# REMOVING THE MOUNTING BRACKET



❶ **Unscrew the screws.**

❷ **Remove the mounting bracket**


# IINSTALLATION OF DIFFERENT CEILINGS




## FOR CONCRETE CEILING

1. Marking screw holes in the ceiling
2. Punching holes in the ceiling with an electric drill
3. Remove Expansion Screws (A) and Install (B) in Ceiling
4. Install the mounting bracket and install the washers and screws (A) in sequence


**IMPORTANT :**
**SCREWS & NUTS MUST BE TIGHTENED TILL SNUG**




## FOR WOODEN CEILING

1. Install the mounting bracket with self-tapping screws and electric

**IMPORTANT :**
**SCREWS & NUTS MUST BE TIGHTENED TILL SNUG**





## FOR JUNCTION BOX

1. Install the mounting bracket with screws

**IMPORTANT :**
**SCREWS & NUTS MUST BE TIGHTENED TILL SNUG**


# INSTALLATION STEPS

## PART 1 Fixed the ceiling fan





1. Using the metal cord, hang the fan from the mounting bracket

## PART 2 Connect the power wire





1. Connect the power wire.
   **Black to AC L, White to ACN**
2. Connect the ground wire

## PART 3 Mounting screw





1. Install two screws in the bracket, they should be 180° relative to each other
2. Screw the 2 screws in halfway

## PART 4 Install the ceiling fan




1. Align the screw holes in the fan with the screws on the bracket
2. Push the fan up to get the screws into the holes
3. Rotate the fan clockwise to hold the fan in place

# INSTALLATION STEPS




❶ Install the remaining 2 screws to the bracket

❷ Tighten all screws

# MAINTENANCE

**Due to the fan' s natural movement, connections may get loose after a period of usage. To ensure a proper and safety usage, inspect the suspension system and tighten all connections every 6 months.**

## CLEANING

**Cleaning your fan periodically will prolong its useful life. Basic cleaning procedures are as follows:**


1. Please turn off the power before cleaning the fan light.
2. After the power is turned off, the light source and its nearby components will still be very hot. To avoid burns, please clean them after they have cooled down.
3. Don' t use sandpaper, wire brush and other sharp tools to clean the light fan.
4. Don' t clean the light fan by using detergents, acid or alkaline solvents.
5. Use only soft or lint-free cloth to clean the light fan.
6. Please dry the ceiling fan by cold-blast air after cleaning, in order to prevent dangerous leakage caused by water infiltrated into electriferous parts of the light fan or prevent rust of wet metal parts.
7. There is no need to oil the fan.

## INSTALLING THE REMOTE CONTROL HOLDER

1. Remove the remote control bracket from the remote control

2. Attach the remote control holder with the two control holder mounting screw provided.


3. Replace the remote control holder cover into remote control .



# OPERATION

IMPORTANT: If you have two or more fans,please follow steps below to control each fan independently.Also follow steps below to re-pair the remote and the receiver when needed

Install battery(not included).To prevent damage to transmitter remove the battery if not used for long periods of time.




| | |
|---|---|
| ALL OFF | Turn off the fan and lights, and press and hold to clear the code |
| ON OFF | Turn on/off the lights. |
| K | Switch color temperature |
| | sleep mode |
| K + | enhances color temperature |
| K − | reduces the color temperature |
| + | enhances brightness |
| − | reduce brightness |
| SETUP | Press and hold within 5 seconds after power-on The flashing lights indicate that the code is complete |
| F/R | sets fan direction forward or reberse. |
| 2h | Short press to set a 2-hour timer, long press to turn off the beep sound |
| 1-6 buttons | 1/2/3/4/5/6 for fan speeds. |
| | Long press natural wind |
| FAN OFF | Turn off the fan |

**NOTE:**
Please insert 2 batteries before using. AAA 1.5V battery x 2pcs (not included).

If the pairing is successful, the lighting kit of the fan will flash.

NOTE:If the self calibration test failed, turn the AC power off；restore power and process the self calibration test again.

# TROUBLE SHOOTING

| Problem | Solution |
|---|---|
| • **The fan can not start.** | • Check the main and branch circuit fuses or breakers.<br>• Check the line wire connections to the fan and switch wire connections in the switch housing. |
| • **The remote control doesn't work.** (For safety clearance, we didn't provide the batteries for the remote control.) | • Re-pairing the remote and controller<br>①Turn off the fan power or room power, then turn on again.<br>②After the buzzer sounds, press and hold the set button within 5 seconds. The flashing light indicates that pairing is complete<br>③Solved!<br>• Replace the remote and controller<br>If the previous step is not effective, please contact us. We will help to send you the replacement part. |
| • **The fan is noisy.** | • Ensure all motor housing screws are installing snugly.<br>• Ensure all the screws that attach the fan blade bracket to the motor hub are tight.<br>• Ensure the wire nut connections are not ratting against each other or the interior wall of the switch housing.<br>• Allow a 24-hour "breaking in" period. Most noises associated with a new fan disappear during this time.<br>• Ensure that the canopy maintains a short distance from the ceiling and should not touch it. |
| • **Missing Accessories**<br>• **Missing Mounting Hardware**<br>• **Damaged Outer Packaging Box** | • Please contact with our service team, we will always 24/7 here for you. Just explain the situation you meet, provide problem photos. We will serve you wholeheartedly and send you the missing part replacement for free. |
| • **If you meet such fan and light functions cannot realize as we describe in the link** | • Please check all the connections are right, if you can't tell what went wrong, please contact us and we'l help you solve it. |