

# Instruction Manual

---

## Cast Iron Garden and Patio Swing w/Frame



# Warranty

## Limited 1-Year Manufacturer Warranty

### **Manufacturer warranty covers:**

- Parts that are deemed defective within 30 days will be shipped free of charge, within the 48 contiguous states.
- Any warranty claim after 30 days, will require shipping to be paid by the customer.


Any visible damage due to the neglect, misuse, or abuse will void the limited warranty of the product.

For further information, please contact us:


# Contents

<b>Contents .....</b>	<b>2</b>
<b>What is included .....</b>	<b>3</b>
<b>Assembly instructions .....</b>	<b>4</b>
<b>YouTube video instruction .....</b>	<b>5</b>
<b>Warranty .....</b>	<b>6</b>

## What is included



## Assembly instructions



1. Connect the main beam and legs to form the top frame structure.
2. Finish assembling the frame structure by placing the bottom stability crossbars.
3. Assemble the swing seat by securely connecting all its parts together.
4. Hang the swing seat onto the swing frame and you are ready to enjoy your swing.

Note: Cushions are not included with the purchase.