

Clean & Care

Roller Shades / Roman Shade Panel System / Vertical Blinds

****Do Not** wash, use strong detergents, or spot removers. Dry cleaning is not recommended. ******
Use a slightly damp cloth to blot gently or a vacuum with an upholstery attachment to clean your Chicology shades when dusty. Be careful not to wrinkle or crush the fabric when cleaning.

Wood Blinds

**** Do Not** use water, strong detergents, or abrasive solutions to clean the blind; can cause damage. ******
Use a slightly damp cloth, you can either clean the blind hanging in place or you can take it down.

Hint: By tilting the slats down slightly, but not quite closed, you'll be able to clean most of the top surface of each slat.

* **Decorative Cloth tape:** Use a soft sponge or cloth moistened with lukewarm water, blot gently.

Cellular Shades

****** Avoid contact with window cleaning products. ******

Use a feather duster or a vacuum with an upholstery attachment; brush lightly over the shade. Or use a lukewarm damp sponge and lightly dab the shade.

* Note *

Be careful not to scratch or damage the products when cleaning!