

Assembly Instruction for SIDE CHAIR

C319


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please Put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST			
No.	PART DESC		Q'TY
A		BACK FRAME	1
B		CUSHION WITH FRAME	1
C		FRONT LEG	2

HARDWARE LIST			
No.	HARDWARE DESC		Q'TY
1		ALLEN BOLT (5/16*50mm)	11
2		FLAT WASHER (5/16*22*1.5mm)	11
3		SPRING WASHER (5/16)	11
4		ALLEN KEY (M5*60mm)	1

STEP 1: Do not tighten the bolts of seat cushion with back rest.




STEP 2: Do not tighten the bolts from side seat cushion with the bottom wing of back rest.



Assembly Instruction for
SIDE CHAIR
C319

STEP 3: Tighten screw untill last step



STEP 4: Completed

