


Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over.


- Place heaviest items in the lowest drawers.
- Do not set TVs or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawer, door, or shelves.
- Never open more than one drawer at a time.
- Use of tip-over restraints, only reducts, but does not eliminate, the risk of tip-over.
- Never open more than one drawer at a time.
- Use of tip-over restraints, only reducts, but does not eliminate, the risk of tip-over.




Never let liquids or damp cloths sit on this furniture.




Never use chemical cleaning products. They can damage the finish. For cleaning, use only a slightly damp cloth and wipe dry.



To avoid dulling of finish,do not place furiture in direct sunlight



Do not put plastic or rubber rings under appliances. Use cloth of felt protectors.



To clean, use a soft or slightly damp cloth, the wipe with a clean, dry cloth.

Schwere oder tödliche Quetschverletzungen können durch Umkippen von Möbeln auftreten. Um ein Umkippen zu verhindern.


- Lege die schwersten Gegenstände in die untersten Schubladen.
- Legen Sie keine Überlastungsobjekte auf die Oberseite dieses Produkts.
- Lassen Sie Kinder niemals klettern oder an Schubladen, Tür oder Regale hängen.
- Öffnen Sie niemals mehr als eine Schublade gleichzeitig.
- Das Umkippen der Rückhalteeinrichtung eliminiert nicht das Risiko eines Umkippens.
- Öffnen Sie niemals mehr als eine Schublade gleichzeitig.




Vermeiden Sie das Versprühen oder Eindringen von Flüssigkeiten auf die Produktoberfläche.



Verwenden Sie keine chemischen Reinigungsmittel. Sie können das Produkt beschädigen und müssen nach Abschluss der Reinigung nur mit einem leicht feuchten Tuch trocken abgewischt werden.



Um ein stumpfes Finish zu vermeiden, stellen Sie Furiture nicht in direktes Sonnenlicht.




Legen Sie keine Kunststoff- oder Gummiringe unter Geräte. Verwenden Sie ein Tuch aus Filzschutz.




Verwenden Sie ein weiches oder leicht feuchtes Tuch, wischen Sie es mit einem sauberen, trockenen Tuch ab.

Tools Required For Assembly





Need Two or More People To Complete






Assemble Item On a Clean Flat Surface








- Please check you have all hardware before assembling.
- Please ensure you have the name of the item and hardware part required and quantity.
- Please contact us by mail, if you have any questions, and we will reply you asap.
- Enjoy your new purchase!


Tips Before You Start

QUICKFIT




Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.

CAM LOCK






When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.


















Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.




Turn cam lock clockwise to tighten.



1
17
4
16
15
6
9
12
5
3
12
2
14
13
11
10
7
8


Ax18+1 	Bx18+1  ϕ15x10mm	Cx28+1 	Dx5  ϕ 4x35mm
E x 8 	Fx4+1  ϕ 3x14mm	Gx2 	Hx8 
I x 36+1  ϕ3x12mm	Jx4 	Kx4  ϕ4x16mm	Lx4 
Mx1 	Nx6 	Ox1 	Px1  ϕ4x12mm
Qx1 	Rx28+1  ϕ 3x12mm		


①  1PC	②  1PC	③  1PC	④  1PC
⑤  1PC	⑥  1PC	⑦  1PC	⑧  1PC
⑨  1PC	⑩  1PC	⑪  1PC	⑫  2PC
⑬  1PC	⑭  1PC	⑮  1PC	⑯  1PC
⑰  1PC			


1




















Fx2	Gx1	Px1	Ax18	Cx2	Qx1
ϕ 3x14mm		ϕ4x12mm			

2








Cx4





3



Cx4	Dx4
	 ϕ 4x35mm


4






F x 2	G x 1	C x 5	B x 5
ϕ 3x14mm			ϕ 15x10mm


5






Cx5	Bx5
	 ϕ15x10mm

6




7





Bx4	Cx4	Nx4
 ϕ15x10mm		


8





Bx4	Cx4	Nx4
 ϕ15x10mm		















Hx8	I x20	Jx4	Kx4	Lx4
	 ϕ3x12mm		 ϕ4x16mm	


10



I x16

ϕ3x12mm


11




E x 8



12








Rx28+1


ϕ 3x12mm

13











Ox1	Dx1	Mx1
	 ϕ 4x35mm	

Tips Before You Use





Serious or fatal crushing injuries can occur from furniture tip-over.
To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.