


# INSTRUCTIONS FOR YOUR PRODUCT


## Step 1

Remove the cable of the fire box and connect it to the transformer.




## Step 2

Connect the flexible hose to the pump. Place pump inside bottom of cavity.



## Step 3

Fill the reservoir with water and take a note of the level that the water reaches for future reference when topping off. Pump should be fully submerged in water.



## Step 4

Plug in pump and transformer and switch on. After a short while the water will start to flow. Add water as needed.

Adjust the pump flow rate to achieve the desired effect and to minimize any splashing. Splashing can occur if the flow rate is too high or the feature water level is too full. The flow rate can be increased or decreased by moving the flow rate control slider on the pump body. Moving the switch towards (+) will increase the flow rate and moving it towards (-) will decrease it.

### WARNING:

Never turn on the pump before the fountain is full of water. Also do not let the water level fall below the top of the pump as the pump will become damaged if run without water. Fountain should be placed on a level surface.

**THANK YOU  
FOR YOUR PURCHASE**