


Standard Pop up Canopy

You'll receive one (1) box only for pop up canopies (MODEL: #PUC03MSCL01 & PUC07MSCL01 & PUC09MSCL01 & PUC03MSCL & PUC07MSCL & PUC09MSCL & PUC03MCL01 & PUC07MCL & PUC09MCL & PUC03CCL). Please pay particular attention to making sure all parts are numbered and graphically indexed as shown on the **Parts List** below, so does the quantity for each part. If you need any help, please CONTACT THE SUPPORT TEAM with the **ORDER NUMBER, REQUIRED PARTS (NAME, QUANTITY, AND PART NUMBER), PICTURES (OR VIDEO CLIPS, IF APPLICABLE)**, we'll get back to help out soon.







Parts List





Reminders

- We recommend you put your canopy into the Carry Bag (#C) whenever storage or transportation is required.








**#PUC03MSCL & #PUC07MSCL & #PUC09MSCL & #PUC03MSCL01 &
#PUC07MSCL01 & #PUC09MSCL01**

Part Number	Diagram	Description	Quantity
#A		Frame (See Details Below)	1
#B		Roof Cover	1
#C		Carry Bag	1
#D		Detachable Wheels for Carry Bag	1
#E		Guyline	4
#F		Stake	8
#H		Mesh Sidewall	2
#K		Sand bag	4

Details for Frame (#A)

#1		Center Lock	1
#2		Leg	4
#4		X-Shaped CrossBar	4
#6		Y-Shaped Bar	4
#7		Top Support Bar	4
#8		Center Support Bar	4


#PUC03CCL & #PUC03MCL01 & #PUC07MCL & #PUC09MCL

Part Number	Diagram	Description	Quantity
#A		Frame(See Details Below)	1
#B		Roof Cover	1
#C		Carry Bag	1
#D		Detachable Wheels for Carry Bag	1
#E		Guyline	4
#F		Stake	8
#I		Sidewall with Window	2
#J		Sidewall with Zipper	2
#K		Sand bag	4
Details for Frame (#A)			
#1		Center Lock	1
#2		Leg	4
#4		X-Shaped CrossBar	4
#6		Y-Shaped Bar	4
#7		Top Support Bar	4
#8		Center Support Bar	4


Assembly

- Please check to make sure that you have all the parts listed in the **Parts List**.
- We recommend at least 2 adults for the assembly.
- **This product includes a tutorial video to help you assemble it, please visit the website where you purchased it.**

Step 1 Take out the pre-assembled frame, slowly unfold it so that you can easily drape the Roof Cover (#B) over the frame at the 4 corners (with built-in Velcro strips).



Step 2 Attach the 4 corners of the roof cover to the frame by matching the Velcro strips on each frame corner, then fully unfold the frame.




Step 3 Find the Center Lock (#1) inside the frame, grasp it, and push it up until it is connected to the Center Pole. Please make sure they are tightly locked before moving to the next step.




Step 4 Adjust the tent to a proper height by pushing down the leg-release button.

Note: There are 3 height options.




PUC03MCL、PUC03MSCL、PUC07MSCL、PUC09MSCL



PUC03NSCL、PUC03MCL01、PUC09MCL、PUC030CC L

Step 5 According to your needs, use the built-in hooks to connect the side walls to the frame




PUC03 MSCL、PUC07 MSCL、PUC09 MSCL
MODEL: PUC03MS/PUC07MS/PUC09MS



PUC03CC L



PUC03 MCL0 1、PUC09 MCL、PUC07MCL



PUC03 MCL

Step 7 Secure the whole structure with the anchoring accessories.

Reminder: You can also use some extra weights (for example, sandbags) to weigh down your canopy.



PUC03 MSCL、PUC07 MSCL、PUC09 MSCL
MODEL: PUC03MS/PUC07MS/PUC09MS

