


DESK WITH STORAGE SHELF

USER MANUAL



Contents

1 PRE-INSTALLATION PREPARATION 01

1-1 Thank You For Choosing Our Product 01

1-2 Package Contents 01

1-3 Precautions 01

2 INSTALLING MODULES02-14

2-1 Disassembly Diagram 02

2-2 Parts List03-04

2-3 Assembly Instructions05-14

3 CUSTOMER SERVICE 15

3-1 30-Day Return Policy 15

3-2 1-Year Warranty 15

3-3 Quick Response Within 24 Hours 15

4 PROBLEMS YOU MAY ENCOUNTER 16

Thank you for choosing our product.

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included.

Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


Package Contents

Desk With Storage Shelf

Assembly Tool Kit

Instruction Manual

Precautions




1. Avoid long-term direct sunlight exposure.



2. Keep away from heat.




3. Keep away from sharp objects.



4. Keep infants/children away from assembly parts to avoid choking and suffocation.




5. Keep away from corrosive substances.



6. Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.

Disassembly Diagram























Parts List

For ease and safety, we recommend two people for assembly.




A x3 	B x1 	C x1 	D x1
E x1 	F x1 	G x1 	H x1
I x1 	J x1 	K x1 	L x1
M x1 	N x1 	O x1 	P x1

Parts List

Q x1 	R x1 	S x4 	T x1 
U x1 	1 x14  M6*12 2 Spares	2 x26  M6*30 3 Spares	3 x15  M6*35 2 Spares
4 x3  M6*28 1 Spare	5 x7  M6*40 1 Spare	6 x1 	7 x4 
8 x9  M6 1 Spare	9 x2  M6 2 Spares	10 x2 	11 x1 
12 x1 	13 x1 	14 x3  ST4*9 1 Spare	15 x9  ST4*10 1 Spare

Assembly Instructions




1



B x1		F x1		G x1		H x1		8 x8	
----------------	---	----------------	---	----------------	---	----------------	---	----------------	---

Assembly Instructions


2



C x1		U x1		3 x4		10 x1	
----------------	---	----------------	---	----------------	---	-----------------	---


Assembly Instructions

3



4


Please note that the holes in part K should be upward.




Assembly Instructions





5


Please note that the hole indicated in section E should be pointed upwards.

E	
x1	
3	
x3	
10	
x1	







6


I	
x1	
Q	
x1	
4	
x1	
10	
x1	



Assembly Instructions




7


Q	
x1	
4	
x1	
5	
x2	
10	
x1	



8

Please note that ensure that the hole on component D is upwards. The two threaded holes indicated on part B shall be outwards.





D	
x1	
3	
x2	
10	
x1	




Assembly Instructions





9


Please note that the three groups of holes on the N main table top need to be upward, and the three groups of holes need to be on the L shaped straight face of desktop to installation of the upper monitor stand.

N	
x1	
O	
x1	
2	
x10	
10	
x1	




10

A	
x3	
P	
x1	
2	
x6	
10	
x1	





Assembly Instructions


11



12






13




L x1		M x1		1 x8		10 x1	
---------	--	---------	--	---------	--	----------	--




Assembly Instructions


14

R	
x1	
5	
x4	
10	
x1	



15



T	
x1	
1	
x2	
10	
x1	




Assembly Instructions

16

X 4



17



Customer Service



30-DAY Return Policy

If you're not completely satisfied with your purchase, simply return the merchandise via our official customer support. Unused merchandise can be refunded or exchanged within 30 days from the original purchase date.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Having issue(s) while reading the instruction or completing the assembly.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of somescrew holes.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The screw holes that on the board and the steel frame don't line up.	1. Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjusting board and steel frame until the screw holes are lined up, then tighten all the screws.
	The desk board is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the desktops are flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Steel Frame	The steel frame is bent, broken, painted, rusted or damaged.	You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
	The table is unstable after being assembled.	1. Check if the screws are tightened. 2. Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3. If your problem still can't be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.