



DOG KENNEL COVER INSTRUCTIONS

- A** 
4X9HTB = 5 pc 57.25 inch Pipe with Buttons
- B** 
4X6HTB = 1 pc 54 inch Swaged Pipe with Buttons
- C**  
3WAHTB = 6 PC 3-way fitting BALL = 16 PC Ball Bungees
-  SC1313 = 4 Sets Clamps w/ Bolts, Nuts and Washers
- 
TKC1010 = 1 pc 10 X 10 Kennel Cover


1) Layout Parts on Ground.



2) Assemble One End of A Frame by Attaching Clamps on Both Sides to Kennel Cage and Insert Pipes and Fitting as Shown Below.



3) Add Center Ridge Section and Complete the Frame Setup by Repeating



WARNING:

Keep all flame and heat sources away from this tent fabric. Meets the flammability requirements. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. For warranty and return authorization information,

4) Drape Cover Over Frame and Attach with Ball Bungees. Finished Kennel Cover Should Look Like Image Below.



5) Instructional Assembly Video Available on Our Website

WARRANTY INFO

Missing/Defective Parts

We try our best to eliminate any defective parts that are shipped with our products. Carefully inspect all packages upon arrival and report any missing or defective items upon receipt. Any discrepancies must be reported to within 30 days of purchase. Please be sure to take a few minutes to match all items in the box to the items on the product manual. If there should be any missing or defective items, we will ship them free of charge. You will need to fill out a warranty claim form and e-mail, fax, or mail it in along with a proof of purchase showing the date of purchase. Your replacement will be shipped free of charge by ground shipping. Next day or express shipping will require freight collect and paid for by you. Damages from improper anchoring, strong winds, snow, ice, or rain are not considered defects.

1 Year Limited Warranty

All of our components feature a 1-year limited warranty (90 day-limited on Value Brand items) and are warranted to be free from defects in material and workmanship during this time frame. You must fill out our warranty claim form and provide your proof of purchase receipt. This does not pertain to any missing or defective parts in 30 day inspection period.

Defective Returns

If you receive a product that is defective and you wish to return it, please contact our customer service department to receive a return authorization number. All items will be passed through quality control before issuing a credit. You will be contacted upon receipt of your returned merchandise and notified whether your return is accepted or not. If not, you will have the option to receive the product back at your expense.

Improper Anchoring, Strong Winds, Rain, Snow, Ice

does not guarantee these canopies under strong weather conditions (including snow & ice) under any circumstances. These canopies are designed to protect against damages caused by sun, light rain, tree sap, birds, etc. they are not designed to hold roof loads that accompany snow, ice, or heavy rains. If your anchored incorrectly and is blown away, we will not send any free replacement parts for damages. If you know strong weather is predicted- remove the cover or take down the unit completely. The cover is designed to be quickly and easily removed.

Non-Warranty Replacement Parts

If your warranty expires and you need replacement parts & they can't be found. We stock

replacement parts for most of our products. Our customer service department will be pleased to assist you in any way possible.

Certain regions of the country are extremely harsh on covers. Normal wear & tear is not covered under warranty, and should be expected.

In order to receive a discounted or free replacement part, you may be asked to return the part, freight, prepaid, to our warehouse for inspection before we will send a replacement. You must, in all cases, provide a copy of your receipt showing the date of purchase, model number and price.

Return Policy

All returns will require a return authorization number (RA). To obtain an RA, please contact our customer service department. All returns must be submitted after 30 days of purchase date, located on receipt. Any returns submitted after 30 days without an RA number will not be accepted. Credit will be issued upon receipt of product and inspected for damages or excessive wear and tear. The full amount of the product will be credited in the form of original payment minus a 25% restocking fee and shipping and handling.

Safety & Care Information

- Always use your best judgment.
- Do NOT use as a permanent cover.
- Temporary use ONLY. Damages due to weather conditions are not warranted.
- Do NOT set up on a steep incline.
- Never set up in windy, rainy, or snowy conditions. is not intended to serve as protection from such conditions. Use for shade only. Disassemble and properly store after each use.
- Do not let snow or rain accumulate on top.
- Always use an anchoring system.
- Keep your canopy away from all fire sources.
- Do NOT machine wash your top. Mild soap & water with a brush while the is open without the legs extended. Do NOT use harsh detergents or abrasives.
- Do NOT put away your Instant while wet or damp. This promotes mildew. Store DRY.
- For best results in keeping your top clean and avoiding small tears, it is recommended that top be removed and stored in carry bag after each use.
- **Never leave your unattended!**

WARNING: Keep all flame & heat sources away from this tent fabric. This tent is made with fabric that meets CPAI-84 & NFPA 701 specifications for flame resistance. It is NOT fire proof. The fabric will burn if left in continuous contact with any flame source.