




INSTALLATION INSTRUCTIONS



floor	panel	pillar	Foot pads
			
x 1	x 1	x 1	x 4


Connecting piece	Flat head screw	Self tapping screws	Shim	Double headed screw	tool
					
x 1	x 1	x 5	x 2	x 1	x 1

01




Step 1: Use self tapping to secure the connecting piece to the panel

02




Step 2: Connect the pillar and panel with double headed screws

03



Step 3: Install and paste the 4 foot pads onto the base plate

04



Step 4: Align the bottom plate and panel at the right angle, then use flat head screws to connect the bottom plate to the support column, and tighten the screws