


SKU: HY036-Z


ASSEMBLY INSTRUCTIONS

A




A x 1

B




B x 1

C




C x 1

D




D x 1

E




E x 1

H




H x 1

F




F x 1

I




I x 1

G



G x 1



No

Hardware

Fig

Q.ty

1


SCEW M6 x 40mm



1

2

SCEW M7x50mm



2

3

BOLT M6x35mm



4

4


BOLT M6x65mm



6

5



Allen key




1

Step 1


NOTE: ASSEMBLY IN THE CORRECT
DIRECTION OF THE BOLT HOLES




Step 2




Step 3






Step 4




Step 5



Step 6



Adjust height for balance



Adjust low for balance

Care & Maintenance

Caution: You must read this before you proceed

-  ● Not for commercial use. For residential use only.
-  ● Prolonged exposure to rain may cause rusting which can stain floors.
-  ● Do not put hot items directly on furniture surface.
-  ● Do not clean furniture with harsh cleansers or polish.
- ✓  ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-  ● Children should not climb or jump on the furniture.
-  ● Do not write on furniture without a padded barrier to protect the surface.
- ✓  ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-  ● Do not place the product in stone areas or areas that absorb too much sunlight.
-  ● Stains may be removed with mild soap solution and damp cloth.
- ✓  ● Keep away from sources of ignition.
- ✓  ● High-pressure water guns must not be used for cleaning. Dust and pick-up spills using a clean, non-colored, lint-free cloth.