


ASSEMBLY INSTRUCTIONS

30 INCH BATH VANITY





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.


Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"


*** Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!**
*** Please assemble on a clean soft surface to avoid damage.**



Tools Required



(Not included)



(Not included)

IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation

Important – Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions















	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
	Connect the panels together.
	Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.
	To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>

Detail View - CABINET













Identifying the Hardware-Identify the hardware using the illustrations below.








Part List

1		2	
	Side Panel (L) - 1pc		Side Panel (R) - 1pc
3		4	
	Mid Panel - 1pc		Top Side Panel (L) - 1pc
5		6	
	Top Side Panel (R) - 1pc		Top Crossbar Front - 1pc
7		8	
	Top Panel Rear - 1pc		Flip Drawer - 1pc
9		10	
	Flip Drawer Face - 1pc		Mid Frame - 1pc
11		12	
	Bottom Panel Rear - 1pc		Bottom Panel - 1pc
13		14	
	Adjustable Shelf - 1pc		Cabinet Door - 1pc

Part List


15		16	
Left Panel of Door - 1pc		Right Panel of Door - 1pc	
17		18	
Mid Panel of Door - 2pcs		Round Bar - 2pcs	
19		20	
Top Drawer Front - 1pc		Top Drawer Rear - 1pc	
21		22	
Top Drawer Side (L) - 1pc		Top Drawer Side (R) - 1pc	
23		24	
Bottom Drawer Panel - 2pcs		Bottom Drawer Front - 1pc	
25		26	
Bottom Drawer Rear - 1pc		Bottom Drawer Side (L) - 1pc	
27			
Bottom Drawer Side (R) - 1pc			

Hardware List



A  ø6x35mm Three in one bolts(35pcs)	B  ø14.5x12mm Three in one lock(35pcs)	C  ø8xø4x25mm Round head screw(3pcs)
D  ø8xø4x32mm Round head screw(24pcs)	E  Handle(5pcs)	F  ø5/32"x20mm Handle screw(1pc)
G  ø5/32"x25mm Handle screw(4pcs)	H  Duo Forte (1pc)	I  Rotary Hinge(2pcs)
J  ø6xø3x12mm Flat head screw(8pcs)	K  Damping hinge (2pcs)	L  ø7xø3.5x15mm Flat head screw(12pcs)
M  Laminate pad(4pcs)	N  ø8x30mm Wood dowel(36pcs)	O  Anti fall hardware(1set)

STAP: 1

A




31PCS




Don't lean




Don't over tighten




STEP: 2



STEP: 3




STEP: 4



B		N	
6PCS		6PCS	


STEP: 5




C		I		J	
2PCS		2PCS		4PCS	


STEP: 6

B		N	
6PCS		6PCS	




STEP: 7

H		J	
1PC		4PCS	




STEP: 8



B		N	
6PCS		6PCS	


STEP: 9




D		N	
8PCS		4PCS	

STEP: 10

A



4PCS



STEP: 11

B




4PCS


N



4PCS






STEP: 12




K	L
	
2PCS	4PCS

STEP: 13




E	F	G	L
			
2PCS	1PC	1PC	8PCS


Use the screws to adjust up or down




Use the screws to permanent




Use the screws to adjust left or right





Use the screws to adjust in or out




STEP: 14


M**4PCS**

STEP: 15

D**8PCS**


STEP: 16

E		G	
1PC		1PC	





STEP: 17

D	
8PCS	




STEP: 18



E		G	
2PCS		2PCS	



STEP: 19




STEP: 20




STEP: 21

Install the sink on the cabinet with glue.
Let stand for 24 hours




*Silicone glue is not included
in the package to comply
with safety regulations in
certain shipping conditions.

STEP: 22



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

