



INSTRUCTIONS MANUAL

Half Round Rattan Armrest with Curved Shape Sofa

Loosely assemble before tightening.

Lost accessories or parts costs will be incurred after 90 days of the date of purchase.

WARNING:

Proper use of the sofa is for single person seating only. The sofa is not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only. Sofa tested for use at weight of 750lb (341kg). Improper use of this product or failure to use as directed may result in injury. Not intended for commercial use.

IMPORTANT:

Please read all the instructions and warnings before assembling. In order to make the whole product adjust to the best, please install all the screws on the product before fully tighten, and note to put the washer to the screw before putting the screw into the screw hole.





SAFETY INFORMATION:





- Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the product construction.
- Keep assembly area at least 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line or electrical wires.
- Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- Check all bolts for tightness before use. **IMPORTANT** - check and tighten bolts often to keep them secure!
- The sofa is not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only.
- The sofa use at weight of 750lb (341kg). Improper use of this product or failure to use as directed may result in injury. Not intended for commercial use.


CARE & MAINTENANCE :





- **STAIN RESISTANT CUSHIONS CARE :KEEP THE CUSHIONS IN STORAGE IN RAINING DAY.**
- **SPILLS:** Immediately wipe up the spill using a white damp cloth. Repeat process if necessary until stain is gone. Allow cushion to air dry.
- **FABRIC CARE:** Hand wash cold, non-chlorine bleach when needed, lay flat to dry. Cool iron if necessary. Do not dry clean.
- **RESIN WICKER PRODUCT CARE:** Before using, clean the product completely with a soft dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water, rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. Over time nuts and bolts can loosen. Occasionally, check nuts and bolts, re-tighten if necessary.
- **Warranty period:** 180 days.

Assembly Instructions


AL	AR	B	C
			
AL 1PC Left Arm	AR 1PC Right Arm	B 1PC Left Sofa Back	C 1PC Right Sofa Back


D	E	F	G
			
D 1PC Left Front Panel	E 1PC Right Front Panel	F 2PC Side Seat Panel	G 1PC Middle Seat Panel

H	I	J	K
	 M6*35mm	 M6*20mm	 Ø16*Ø6.5*1mm
H 1PC Middle Foot	I 24PC Bolt	J 4PC Bolt	K 28PC Washer

L	M	N	O
			
L 1PC Allen Wrench	M 2PC Side Seat Cushion	N 1PC Middle Seat Cushion	O 3PC Back Cushion


Tools:






Ratchet Wrench


1. Attach two sofa backs (B&C) to each other with 2 bolts (I) and 2 washers (K) by using allen wrench (L). **Keep the bolts fully tightened.**




I		M6*35mm	2
K		Ø16*Ø6.5*1mm	2



2. Attach two front panels (D&E) to each other with 2 bolts (I) and 2 washers (K) by using allen wrench (L). **Keep the bolts fully tightened.**




I		M6*35mm	2
K		Ø16*Ø6.5*1mm	2



3. Secure sofa arms (AL&AR) to assembled sofa backs (B&C) with 4 bolts (I) and 4 washers (K) by using allen wrench (L). **Keep the bolts loose.**




I		M6*35mm	4
K		Ø16*Ø6.5*1mm	4

4. Secure assembled sofa arms (AL&AR) to assembled front panels (D&E) with 4 bolts (I) and 4 washers (K) by using allen wrench (L). **Keep the bolts loose.**




I		M6*35mm	4
K		Ø16*Ø6.5*1mm	4

5. Secure middle foot (H) to middle seat panel (G) with 4 bolts (J) and 4 washers (K) by using allen wrench (L). **Keep the bolts loose.**



6. Secure side seat panels (F) & assembled middle seat panel (G) to assembled sofa backs (B&C) and assembled front panels (D&E) with 12 bolts (I) and 12 washers (K) by using allen wrench (L). **Keep the bolts loose.**

Note: Seat panels with arc shape should face sofa backs.



7. Tighten all bolts, put cushions (M. N&O) onto the sofa, it is ready to use now.

