



## User Manual

A1EMERGENCYLIGHT  
A3EMERGENCYLIGHT



### Instructions

#### ● Flashlight Function:

Remove the light from the charging base. Press the ON/OFF button once and it turns on the front LED. Press again and it turns on the top LED. Press again and it turns off.

Please note that the motion sensor feature will deactivate when using the flashlight in flashlight mode. Press the ON/OFF button while the flashlight is in the charging base to turn off the light and reactivate the motion sensor.

#### ● Sensor Function:

When the flashlight is placed in the charging base and plug into a power outlet, it will turn on automatically if its dark and motion is detected in front of the sensor. After around 25 seconds the light will switch off automatically. This sensor light feature is made to help save electricity.

#### ● Emergency Function:

The product is placed in the charging base, if there is a power outage, the LEDs at the front of the light automatically light up. The ON/OFF button will continue to operate as stated above.

#### ● Rechargeable Function:

The light has a wireless charging function. Simply stand it in the charging base while the base is plugged into an outlet and it will automatically charge. When the light is fully charged, the charging will stop. There is no need to remove it from the charging base.

### Main Parameters

- |                         |                       |
|-------------------------|-----------------------|
| ● Adapter type:         | ● Work time: 15LED    |
| AC120V 60HZ 0.04A       | >1.5H, 5LED>3H        |
| ● Battery type:         | ● Sensor details:     |
| 502030 3.7V             | 25s+-5s Sensor        |
| 250MAH                  | distance: 2-3m        |
| ● Front light: 5pcs LED | ● Fully charged time: |
| ● Top light: 15pcs LED  | 6-7hours              |

Sensor: Distance will reduce the motion detection

Copyright 2018 Bluetech  
and Distributed by BHRS Group LLC