

# FLOOR LAMP

INSTALLATION MANUAL

## WARNING:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET REVERSE THE PLUG, IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

- \* Do not plug the power cord into the outlet until fully installed.
- \* Do not exceed the recommended wattage.
- \* Always allow bulbs to cool for 10 minutes before changing.

This fixture has been rated for up to **five (5) E26 Socket 60-Watt maximum** standard incandescent light bulb (not included) or **CFL** or **LED** bulb (not included).

To avoid the risk of fire, **DO NOT EXCEED THE RECOMMENDED LAMP WATTAGE.**

The lighting fixture is meant for indoor use.

Pls read the installation instructions carefully and follow the steps:

1. Connect the poles (B1, B2) and the base (A).
2. Attach the light bulbs (not included).
3. The height of fixture can be adjusted up and down.
4. The angle of head can be adjusted up and down by 90 degrees.

