

your global source for unique lighting + home decor

ASSEMBLY INSTRUCTIONS

1. Place all parts on a flat smooth surface.
2. Connect the tube(B)s to the base(A) and secure with the washer and screw using the Allen key.
3. Connect top part (C) to the tube (B) .
4. Install the Shade(D)on the Socket and secure with the Socket Ring (E) .**(Socket Ring located on socket)**
5. Install Bulb(F) (Not included)


! CAUTION - Refer to the wattage caution label located near the lamp holder for maximum wattage - do not exceed the maximum wattage.

! WARNING - Do not attempt to replace the bulb(s) while the lamp is plugged into a wall receptacle

CARE INSTRUCTIONS - Use only a soft cloth; do not use any chemicals or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit it, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.



E12 Type B.40W X 2 (Not included)

E12 CFL 7W X 2 (Not included)