



ASSEMBLY INSTRUCTIONS











SKU:WF306331/ WF306332




Detail View




Part List

A  Headboard-1PC	B  HB Leg-2PCS	C  Side Rail-2PCS
D  Footboard -1PC	E  Crossband-1PC	F  Support Rail-2PCS
G  Center Crossband-1PC	H  Support Leg-2PCS	I  Center Support Leg-1PC
J  FB Feet-2PCS	K  Side Rail Feet-2PCS	L  Slats-2PCS
M  SR Bar-4PCS	N  LED Light Belt-1SET	

Hardware List


1	 5/16"×25mm Bolt (14pcs)	2	 5/16"×50mm Bolt (13pcs)	3	 1/4" x 17mm Bolt (12pcs)
4	 5/16"×19mm Flat Washer (31pcs)	5	 5/16" Allen Key (1pc)	6	 M8×25mm Screw (24pcs)
7	 5/16" Nut (4pcs)	8	 5/16" Box Wrench (1pc)	9	 1/4"×38mm Bolt (12pcs)
10	 1/4"×16mm Flat Washer (24pcs)	11	 1/4" Allen Key (1pc)	12	 M8×15mm Screw (16pcs)
13	 Coupon (2pcs)				

STEP 1



2		4	
4PCS		4PCS	



STEP 2



1		4	
4PCS		4PCS	



STEP 3

3	10	12
		
4PCS	4PCS	16PCS




STEP 4

9	10
	
12PCS	12PCS




STEP 5



3		10	
8PCS		8PCS	


STEP 6



1		4	
8PCS		8PCS	


STEP 7

2		4		7	
4PCS		6PCS		2PCS	




STEP 8

1		2		4		7	
2PCS		2PCS		6PCS		2PCS	




STEP 9

2	4
	
3PCS	3PCS



STEP 10




STEP 11

6



24PCS



STEP 12

N



1Set

