

ATTENTIONS

1) After installation, in order to ensure that the chair can work normally, please follow the steps below to check:


- ① Check all the cables are connected correctly.
Check if the cables under the seat is loosed or not.
The red wire should be connected to the red one.
The white wire should be connected to the white one.
- ② Check if the light of the transformer is on.
- ③ Check if the light of remote is on.
- ④ Make sure the motor have a weak buzz (48 decibel) if the three above steps are normal.
- ⑤ Use some lubricant on the joints motor and mechanism of the chair.

2) If the chair does not work properly, please tell us your checking result. It is best to shoot video and send it to our e-mail, we can understand your problem faster and more accurately. Any questions or concerns, please contact us.

Our engineer will see where is wrong with the chair and provide you a satisfied solution. (If the parts were broken, we would like to send the replacement parts to you.)

Specializing in living-room furniture. It researches, develops, manufactures and sells upholstered furniture with the aim to build a comfortable and eco-friendly environment.

Motion — our brand core conception, ergonomics and comfort, which is the most extraordinary beauty in the upholstered furniture. Devotes to provide high quality sofa enjoyment for millions in the world by its simplified American style





CONTENT

P1. Attention

P2. Brand Story

P3. Contents

P4. Product Specifications

P5. Accessories & Installation guidance

P6. Installation guidance



P7. Usage Information

P8. Clean Tips

P9. Attention

■

Recliner: reclines the chair to 150 degrees, back and footrest work together fully powered by the remote to release the built-in footrest.




■









LIFT MECHANISM: push the entire chair up from its base to help the senior to stand.

■

Deluxe Design: this lift chair is the perfect companion for any media room or living room.




FITTING LIST


			
BOX 1	BOX 2	BOX 3	
A 1*Chair Seat	B 1*Chair Back	C 1*Left Armrest	D 1*Right Armrest
			
E Massage Remote	F Power Source	G Power Cord	H 2*Supporting Feet

ASSEMBLY


STEP 1: Place the **Chair Seat (A)** on its back on a flat smooth surface. Take out **Supporting Feet (H)** from a small plastic bag. Assemble the two supporting feet as shown on the bottom of mechanism to avoid toppling and falling.



- **STEP 2:** Insert two **armrests** to the **Chair Seat (A)**, make sure the slots on the armrests fully assembled to the bottom part.



- **STEP 3:** Insert **Chair Back (B)** to the **Chair Seat (A)** , make sure the slots on the back fully assembled to the bottom part.



No.1 and No.2 wire connect with the backrest and chair seat.

No.3 wire connects with backrest and power cord(G).


No.4 wire connects with backrest and massage remote(E).

No.5 wire connect the motor and the wire from rightside armrest which use to connect the control panel.



No.6 wire connect the motor and power source (F).

NOTE

1. Two same color wires connect.
2. Plug both the Power Cord(G) and Power Source (F) into outlet to get the recliner working.



USAGE INFORMATIONS




■ TO STORE OR CLEAN

Maintenance Instructions

Rotate reversible cushions regularly.


Turn over & Rotate



Vacuum your furniture regularly with




Do not expose your furniture to





Do not place your furniture close to a



ATTENTIONS



Moving the chair carefully to avoid falling armrests hurting your feet



Put a carpet under the chair to protect your floor while assembling

