

How to reshape the basket



Basket comes as folded



Will have creases after Opened



Fill it up with towels or clothes, sit for 1-2 days to reshape the basket



Use steamer or iron could reshape it immediately