


Instruction Manual




Parts List


 Ax6	 Bx3	 Cx1	

Assembly Steps 1



Assembly Steps 2





Assembly Steps 3

