


# ASSEMBLY INSTRUCTION



**+ Do Not Use Power Tools**




**+ Suggested Adults**




## + Parts Included

① SOFA BASE  
1PC



② PILLOW  
2PCS




③ BACK CUSHION  
2PCS




④ SEAT CUSHION  
2PCS



⑤ GOLD LEG  
4PCS



⑥ CHROME LEG  
4PCS



⑦ MIDDLE LEG  
1PC



## + Hardware Included

**A ALLEN WRENCH**  
Ø5/16 \*66MM 1PC



**B BOLT**  
M8\*35MM 8PCS



**C WASHER**  
M8\*16MM 8PCS



### NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

### 1 IMPORTANT SAFETY INFORMATION

**Do not** assemble the product if any of the following parts arrived damaged:

- Part # - Sofa Base
- Part # - Pillow
- Part # - Back cushion
- Part # - Seat cushion
- Part # - Gold leg
- Part # - Chrome leg
- Part # - Middle leg

**Do not** assemble if any of the following Hardware parts missing:




- Part # - Allen Wrench
- Part # - Bolt
- Part # - Washer

### 2 IMPORTANT ASSEMBLY INFORMATION

**Assembly Step** If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

# ASSEMBLY INSTRUCTION

1



2

