



ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!




Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

E.KING BED

.....




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

① 1pc



HEADBOARD

② 1pc



HB - LEG LEFT

③ 1pc



HB - LEG RIGHT

④ 1pc




STRETCHER

⑤ 1pc



STRETCHER - X

⑥ 1pc




FOOTBOARD

⑦ 2pcs




SIDE RAIL

⑧ 4pcs



SLAT
1940 x 42 x 17mm

⑨ 8pcs



VERTICAL LEG
219 x 29 x 29mm

HARDWARE

HARDWARE INSIDE HEADBOARD

Ⓐ 12pcs



Bolt M6x30mm

Ⓑ 12pcs



Lock Washer

Ⓒ 12pcs



Flat Washer

Ⓓ 1pc



Allen Key M4

Ⓔ 1pc



Adapter

Ⓕ 4pcs



Panhead Screw
M4x30mm

HARDWARE INSIDE FOOTBOARD

Ⓖ 8pcs



Bolt M8x20mm

Ⓕ 8pcs



Flat Washer

Ⓖ 1pc



Allen Key M5

Ⓖ 8pcs



Panhead Screw
M4x30mm

packed in 3 cartons

CARTON	DESCRIPTION	PART	HARDWARE
	KING HEADBOARD	①  1	 4 x 10 Pcs  2 x 12 Pcs  2 x 12 Pcs  2 x 10 Pcs  2 x 10 Pcs  2 x 10 Pcs
	KING HL-LEG LEFT	②  1	
	KING HL-LEG RIGHT	③  1	
	KING STRETCHER	④  1	
	KING STRETCHER-X	⑤  1	
	KING FOOTBOARD	⑥  1	 2 x 10 Pcs  2 x 10 Pcs  2 x 10 Pcs  2 x 10 Pcs
	KING SLAT	⑦  1	
	KING VERTICAL	⑧  1	
	QUEEN / KING SIDE RAIL	⑨  1	

ASSEMBLY INSTRUCTIONS

1

Part ① 1pc

Part ② 1pc

Part ③ 1pc


Hardware (A) 8pcs

Hardware (B) 8pcs

Hardware (C) 8pcs

Hardware (D) 1pc

Use Allen Key (#D) to attach HB-Leg Right (#2) / Left (#3) to Headboard (#1) by using Bolt (#A) with lock washer (#B) and flat washer (#C).



Using Panhead Screw (#F) to attach Stretcher – X (#5) to Headboard (#1), tighten with Screw Driver.

2

Part ④ 1pc

Part ⑤ 1pc


Hardware (A) 4pcs

Hardware (B) 4pcs

Hardware (C) 4pcs

Hardware (D) 1pc

Hardware (F) 4pcs




Use Allen Key (#D) to attach Stretcher (#4) to Headboard (#1) by using Bolt (#A) with lock washer (#B) and flat washer (#C).

ASSEMBLY INSTRUCTIONS

3

Part ⑥ 1pc
Part ⑦ 2pcs
Hardware ⑧ 8pcs
Hardware ⑨ 8pcs
Hardware ⑩ 1pc




Use Allen Key (#I) to attach the Side rail (#7) to Headboard (#1) and Footboard (#6) by using Bolt (#G) with flat washer (#H).

4

Part ⑧ 4pcs
Part ⑨ 8pcs
Hardware ⑩ 1pc
Hardware ⑪ 8pcs

Attached Adapter (#E) to Headboard (#1).



Attached Vertical Leg (#9) to Slat (#8) then spread slat evenly onto Side Rail (#7) and secure by using Panhead Screw (#J). Tighten with Screw Driver.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.