

END TABLE

ASSEMBLY INSTRUCTION COASTER FINE FURNITURE



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.






Warning!!





- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.

ASSEMBLY TIME PER UNIT: 40 MINUTES


PARTS IDENTIFICATION

<p>A</p> <p>TOP GLASS  1PC</p>	<p>B</p> <p>SIDE FRAME  2PCS</p>
<p>C</p> <p>FRONT AND BACK FRAME  2PCS</p>	


HARDWARE PACKAGE

Z	DESCRIPTION	FIGURE	Q'TY
1	BOLT (1/4"x12mm)		14PCS
2	SUCTION CUP (8mm)		4PCS
3	CAP (20x20mm)		4PCS
4	ALLEN WRENCH (4mm)		1PC

STEP 1



STEP 2



FINISH

