




SOFA
ASSEMBLY
& INSTRUCTION MANUAL

List of important parts



1/4*16mm



R x24



T x1

M5



U x1

8#*25mm



V x2


M4



W x1


STEP 1

M x4
J x4 Q x1




STEP 2

M x4
J x4 Q x1




STEP 3

P x2
J x2




STEP 4

P x2
J x2




STEP 5

K x2 R x8
O x8 W x1




STEP 6

K x2 R x8
O x8 W x1




STEP 7

N x2 P x2 J x4 T x1
L x2 V x2 U x1




STEP 8

Y x2 R x8
O x8 W x1




STEP 9

I x4



STEP 10



After the sofa is unfolded, it is not fully rebounded. It will be soft to sit on. After a certain period of time (24-72 hours), the support will become stronger. This is a normal phenomenon.

Warm Reminder: Different production batches have different rebound times. Some may take longer to rebound to the best effect. If you have any questions about the product, you can contact us. We are always at your service.

Finished product display

