

Cat Tree


ASSEMBLY INSTRUCTION
























ADULT ASSEMBLY REQUIRED

Read all instructions before assembly and use.

Due to the presence of small parts during assembly, keep out of reach of children until assembly is complete.





PARTS LIST

A  1pc	B  1pc	C  1pc	D  1pc	E  1pc
F  1pc	G  2pcs	H  1pc	I  8pcs	25  1pc
25  2pcs	30  1pc	38  1pc	40  2pcs	25+  1pc
6  3pcs	a M8×60  4pcs	b M8×30  26pcs	d M8×16  2pcs	e M8×50  1pc
i 				



WARNING

- Please read the instruction manual carefully before using it.
- Please assemble strictly in accordance with the instruction.
- Please double check to ensure that all parts of the package contents are intact. If any parts are missing, broken, damaged or worn, stop using this product until repairs are made and factory replacement parts are installed.




1





2




3





4






5





6





7





8




9



10



11



12

