


## IMPORTANT SAFETY NOTICE

- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce risk of electric shock. This plug will fit in a polarized outlet only one way. If it doesn't fit fully in your outlet, reverse the plug. If it still doesn't fit, contact a qualified electrician. **NEVER** use with an extension cord unless the plug can be fully inserted.
- Do not plug your lamp in until assembly is completed.
- Periodically check to make sure that all connectors (bolts, screws etc.) are tight.

## ASSEMBLY INSTRUCTIONS

*Before you begin, please review all parts and hardware before you discard any packaging. Refer to the image and key below to identify parts needed.*

Each lamp includes:
A) Base
B) Neck
C) Saddle
D) Socket
E) Harp
F) Lamp shade
G) Finial



### Step 1

Screw the Neck [B] onto the Lamp base [A].

### Step 2

Squeeze both legs of the harp [E] together and guide them into the saddle [C].

### Step 3

Screw a light bulb (included) into the socket [D]. *Note: We recommend no higher than a 100-watt bulb. If you're using an LED bulb, no higher than 12 watts.*

### Step 4

Place shade [F] over the harp [E] and screw on the finial [G] to secure the shade.

### Step 5

Put the lamp on a level surface to make sure that all pieces are stable.