



SF0007

Assembly Instructions




Tools Recommended

This Instructions Contains Important Safety Information. Please Read Before Assembly And Keep For Future Reference.

Need Parts or Assistance? Email us at Riching@nbrehome.com

IMPORTANT NOTICE



- This product contains small components, please ensure that they are kept away from small children.
- **THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.**
- Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- Make sure all parts are included. Most parts are labeled or stamped on the raw edge.
- Work in spacious area, preferably on a carpet, near the place the unit will be used.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.
- Move your new furniture carefully, with two people lift and carry the unit to its new location.
- Never push, drag or pull your furniture (especially on carpet).

PLEASE DO NOT RETURN PRODUCT TO US IMMEDIATELY

- If any parts are missing or damaged, do not return the damaged item to your dealer, contact Customer Service. We will gladly ship you replacement parts FREE of charge!
- Need parts or Assistance? Email us at riching@nbrehome.com
- Thank you for choosing our products.
- For prompt, Reliable Customer Service, Please have your assemble instruction ready.















WARNING

(Death or serious injury may occur when children climb on audio and/or video equipment furniture.)


To reduce the risk of furniture tipover:





- NEVER attempt to move this furniture without first removing all equipment.
- NEVER placing remote control or toys on the furniture, may encourage a child to climb on the furniture and as a result the furniture may tip over onto the child.
- Please contact us using the details shown for further advice.



Step 1




Install the part (A) on the panel⑥,panel⑦.Then insert part (C) into the corresponding holes of panel②, and insert panel⑥ and panel⑦.Then lock them with part(B).
The installation position is as shown in the figure below.



Step 2

Install the part (A) on the panel⑧, panel⑨. Then insert part (C) into the corresponding holes of panel③, and insert panel⑧ and panel⑨. Then lock them with part (B).

The installation position is as shown in the figure below.



Ax10

6x35mm



Bx6

15x5.9mm




Cx4

6x30mm

Step 3

Install the part (A) on the panel④, panel⑤ and panel⑭. The installation position is as shown in the figure below.





Ax8

6x35mm


Step 4

Insert part (C) into the corresponding holes of panel①⑥, and then insert panel④ and panel⑤. Then lock them with part (B).




The installation position is as shown in the figure below.



Step 5




First Insert part(C) into the corresponding holes of panel⑭,then insert panel⑬ and panel⑳ by using part(E).
 Then Insert part(C) into the corresponding holes of panel⑭,and insert the another already assembled cabinet.Then lock them with part(B).
 The installation location is shown in the figure below.




Step 6

Insert panel⑪ into the corresponding groove of panel④ and panel⑤.
The installation position is as shown in the figure below.



Step 7

Insert part (C) into the corresponding holes of panel④ and panel⑤, and then insert panel⑪. Then fix them by using part(E).
The installation position is as shown in the figure below.



Cx4

6x30mm




Ex4

4x35mm

Step 8


Rotate the foot^⑮ onto the panel^⑮ and tighten it.

The installation position is as shown in the figure below.






After adjusting the screw on the center stay foot, please ensure that it is firmly grounded to prevent any potential cabinet collapse caused by hanging.

Step 9



Insert panel^⑩ into the corresponding groove of panel^⑭ and panel^⑮.
The installation position is as shown in the figure below.

Step 10





Then Insert part(C) into the corresponding holes of panel ⑭ and panel ⑰, and then insert panel ③. Then lock them with part(B).
The installation location is shown in the figure below.

Step 11


Then Insert part(C) into the corresponding holes of panel ⑭ and panel ⑰, and then insert panel ②. Then lock them with part(B).
Finally, paste part (N) to the bottom of the legs.

The installation location is shown in the figure below.




Step 12

Insert panel ⑫ into the corresponding groove of panel ② and panel ③.
The installation position is as shown in the figure below.





Step 13

Install the part (A) on the panel ①. Use part (L) to fix part (K) on the corresponding hole position of panel ①. Then insert part (C) into the corresponding holes of panel ②, panel ③, panel ⑬, panel ⑳ and insert panel ①. Then lock them with part (B).
The installation position is as shown in the figure below.





Step 14




Install the part(I) on the panel②,panel③,panel④,panel⑤ and then put the panel⑮ into the cabinet.
The installation position is as shown in the figure below.

Step 15


Use the part (G)and part (H) to fasten the back board buckle.
The installation position is as shown in the figure below.




Step 16




Install the part (J) to the panel^⑲ by part (D).
Then install the panel^⑲ to the side panel by
hinge with part (D).
The installation position is as shown in the
figure below.



Step 17






Installation of anti-tipping decorations.
Installing the cabinet on the wall using
part (M) and part(F).
Paste part(O) to the panel④, panel⑤
and paste part(P) on the holes.
The installation position is as shown in
the figure below.




Step 18


Hinges Adjustment Tips



Loosing screw (D) can adjust the door panel vertically.



Loosing screw(Z) can adjust the door panel horizontally



Loosing screw(Y) can adjust the door panel in-and-out.

