Packing parts



⚠WARNING:

Adult assembly required, Product includes small parts with potentially hazardous sharp points and sharp edges in the unassembled state. Keep unassembled parts away from children.

1、RISK OF FIRE. Do not bypass.

2、This toy contains batteries that are non–replaceable.

3、To reduce the risk of injury, adult supervision is required. Never use in roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water; always wear shoes, and never allow more than 1 rider(s).

4、Only use the battery(ies) specified by the manufacturer

5、Only use the charger(s) specified by the manufacturer.

6、This product can support a maximum weight of 70kg and is suitable for use by individuals aged 3 and above

Children's Twisting Car


Installation and usage instructions



⚠WARNING:

CHOKING HAZARD–Small parts.

Not for children under 3 years.







1. Align the card slot and install the left and right wheel covers of the front wheel



2. Install the support rod onto the front wheel



3. Align the holes and place the screws and nuts



4. Use tools to tighten the screws and secure them in place



5. Align the hole and thread the front wheel through the body, making sure the small wheel is facing forward



6. Install the steering wheel




7. Align the holes, install screws and nuts, and use tools to tighten and secure them



8. Align the card slot and install the left and right wheel covers



9. Open the seat plate



10. Remove the white battery safety helmet and plug the red wire into the battery



11. Charging location