













ASSEMBLY INSTRUCTION



MODELNO.:F10031-L/F10032-L/F10033-L/F10034-L





PARTS LIST

<p>A</p>  <p>X1</p>	<p>B</p>  <p>X1</p>	<p>C</p>  <p>X1</p>	<p>D</p>  <p>X1</p>	<p>F</p>  <p>X1</p>
<p>G</p>  <p>X1</p>	<p>H</p>  <p>X3</p>	<p>I</p>  <p>X2</p>	<p>J</p>  <p>X3</p>	<p>K</p>  <p>X3</p>
<p>L</p>  <p>X1</p>				

Packing list:




Carton 1/8




Carton 2/8

STEP 1:



STEP 2:



Toll-Free number: 1-833-273-2277