


**FULLY ASSEMBLE:**



**WARNING:**



Please avoid unbalance loads on top of the table.







The product should only be used on firm, level ground.









Please periodically check all fittings and re-tighten as necessary.



**Assembly Instruction**

4-Leg Rectangular Smart Top Table



No	Hardware List	Qty
1	Screw JCBB M8x40mm 	8pcs
2	Allen Key M5 	1pc
3	Spring Washer 	8pcs
4	Flat Washer 	8pcs


No	Parts List	Qty
A	Table 	1pc
B	Leg 	4pcs



**USEFUL HINTS BEFORE YOU START:**

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

**STEP 1**



**STEP 2**

