
















ASSEMBLY INSTRUCTION




PARTS LIST

						
A	B	C	Leg			
x1	x2	x4	x1	x1	x1	x1


HARDWARE LIST

						
1	2	3	4	5	6	7
x6	x12	x12	x2	x4	x1	x1

Open up Velcro of Non-Woven Fabric cover on the bottom of the to remove **HARDWARE** and **legs**.



Step1



Step2

